



OWNER'S & INSTALLATION MANUAL

FULL DC Inverter Chiller

KEM-30 DNS3

KEM-60 DNS3

KEM-90 DNS3







Original instructions.

Thank you very much for purchasing our air conditioner. Before using your air conditioner, please read this manual carefully and keep it for future reference.

ACCESSORIES

| | |
|---|----|
| 1. INTRODUCTION..... | 1 |
| 2. SAFETY CONSIDERATION | 2 |
| 3. BEFORE INSTALLATION | 3 |
| 4. IMPORTANT INFORMATION ON REFRIGERANT..... | 4 |
| 5. PRECAUTIONS OF INSTALLATION..... | 4 |
| 6. INSTALLATION OF THE UNIT..... | 4 |
| 7. CONNECTION DRAWING OF PIPELINE SYSTEM | 9 |
| 8. OVERVIEW OF THE UNIT | 10 |
| 9. START-UP AND CONFIGURATION..... | 36 |
| 10. FINAL CHECK AND TEST RUN..... | 37 |
| 11. MAINTENANCE AND UPKEEP | 39 |
| 12. APPLICABLE MODELS AND MAIN PARAMETERS | 47 |
| 13. INFORMATION REQUIREMENTS | 48 |

ACCESSORIES

| Unit | Installation & Operation manual | Total water outlet temperature sensor casing | Transformer | Installation manual of wired controller |
|----------|---|---|---|---|
| Quantity | 1 | 1 | 1 | 1 |
| Shape |  |  |  |  |
| Purpose | _____ | Use for installation (only need for setting the main module) | | |

1. INTRODUCTION

Use conditions of the unit

- a. The standard voltage of power supply is 380-415V 3N~50Hz, the minimum allowable voltage is 342V, and the maximum voltage is 456V.
- b. The unit must be operated as the following outdoor temperature:




Fig. 1-1 Cooling operating range of KEM-30 DNS3 and KEM-60 DNS3




Fig. 1-2 Cooling operating range of KEM-90 DNS3




Fig. 1-3 Heating operating range of KEM-30 DNS3 and KEM-60 DNS3




Fig. 1-4 Heating operating range of KEM-90 DNS3

2. SAFETY CONSIDERATION

To prevent injuries or property losses, make sure to observe the following instructions. Failure to do so may cause injuries or losses.

There are two types of safety instructions: warning and caution. Whichever type it is, you must read the information listed under it carefully.



WARNING

Failure to observe a warning may result injury.



CAUTION

Failure to observe a caution may result injury or damage to the equipment.



WARNING

- Get your distributor or a professional to install the product. The installation personnel must be equipped with the professional knowledge. When you install on your own, any mistake you made during the operations may lead to a fire, electric shock, injury or water leakage.
- When purchasing items locally, purchase those designated by our company.
- Failure to do so may result in a fire, electric shock, or water leakage. Note to entrust a professional to install those items.
- When powering the unit, follow the regulations of the local electric company.
- Make sure the unit is grounded reliably in accordance with the laws. Otherwise, it may cause electric shock. When moving or reinstalling the modular unit, get your distributor or a professional to do so.
- If installed improperly, a fire, electric shock, injury or water leakage may occur. Never modify or repair the unit on your own.
- Otherwise, a fire, electric shock, injury or water leakage may occur. Get your distributor or a professional to do so.



CAUTION

- Ensure that the residual current device (RCD) is installed. The RCD must be installed. Failure to install it may result in electric shock.
- Connect the cable properly. Otherwise, it may cause damage to electrical parts.
- Do not operate the unit near flammables (paint, coating, gasoline and chemical reagents) lest fire or explosion may occur. In the unlikely event of a fire, please turn off the main power immediately and put out the fire using an extinguisher.
- Do not touch refrigerant discharge parts to prevent being burnt.
- Service the unit regularly according to the manual, to ensure that the unit is in good condition. When the unit stops due to a fault, refer to the Fault Analysis and Troubleshooting in this manual, or contact the local customer service centre. Do not start the unit until the fault is eliminated.
- When finding refrigerant or chilled water (cooling water) leaks, turn off all the switches immediately. If you cannot do so through operating the controller, do not restart the unit unless the fault is located and eliminated.
- Use fuses with designated capacity. Do not use iron wires or copper wires, as doing so may result in serious damages to the unit or a fire.

3. BEFORE INSTALLATION

Handling of the unit

The angle of inclination should be between 45° and 70° when carrying the unit in case the machine turns over.

- Rolling handling: several rolling rods of the same size are placed under the base of the unit, and the length of each rod must be more than the outer frame of the base and suitable for balancing of the unit.
- Lifting: each lifting rope (belt) should be able to bear 4 times the weight of the unit. Check the lifting hook and ensure that it is firmly attached to the unit. To avoid damages to the unit, a protective block made of wood, cloth or hard paper should be placed between the unit and rope when lifting, and its thickness should be 50mm or more. It is strictly forbidden to stand under the machine when it is hoisted.




Fig. 3-1 Lifting of the unit

4. IMPORTANT INFORMATION ON REFRIGERANT

This product contains fluorinated greenhouse gases covered by the Kyoto Protocol. Do not vent gases into the atmosphere.

Refrigerant type: R-410A

GWP value: 2088

GWP = global warming potential

Table 4-1

| Model | Factory charge | |
|-------------|-----------------|-----------------------------------|
| | Refrigerant(kg) | Tonnes CO ₂ equivalent |
| KEM-30 DNS3 | 10.50 | 21.94 |
| KEM-60 DNS3 | 17.00 | 35.50 |
| KEM-90 DNS3 | 27.00 | 56.36 |

5. PRECAUTIONS OF INSTALLATION

- Units can be installed on the ground or proper place on a roof, provided that sufficient ventilation can be guaranteed.
- Do not install the unit in a scenario with requirements on noise and vibration.
- When installing the unit, take measures to avoid exposure to direct sunlight, and keep the unit away from boiler pipeline and surroundings which might corrode the condenser coil and copper pipes.
- If the unit is within the reach of unauthorized personnel, take protective measures for safety considerations, such as installing a fence. These measures can prevent man-caused or accidental injuries, and can also prevent the electrical parts in operation from being exposed when the main control box is opened.
- Install the unit on a foundation at least 300 mm high above the ground, where the floor drain is provided, to ensure that water does not accumulate.
- If installing the unit on the ground, put the steel base of the unit on the concrete foundation, which must be as deep as into the frozen soil layer. Ensure the installation foundation is separated from buildings, as the noises and vibration of the unit may adversely affect the latter. By means of the installation holes on the unit base, the unit can be fastened on the foundation reliably.
- If the unit is installed on a roof, the roof must be strong enough to bear the weight of the unit and the weight of maintenance personnel. The unit can be placed on the concrete and groove-shaped steel frame, similar to the case when the unit is installed on the ground. The weight-bearing groove-shaped steel must match the installation holes of the shock absorber and is wide enough to accommodate the shock absorber.
- For other special requirements for installation, please consult the building contractor, architectural designer or other professionals.



NOTE

The selected installation site of the unit should facilitate connection of water pipes and wires, and be free from water inlet of oil fume, steam or other heat sources. Besides, the noise of the unit and cold and hot air should not influence the surrounding environment.

6. INSTALLATION OF THE UNIT

6.1 Outline dimensional drawing

6.1.1 KEM-30 DNS3





Fig. 6-1 Outline dimensional of KEM-30 DNS3

6.1.2 KEM-60 DNS3






Fig. 6-2 Outline dimensional of KEM-60 DNS3

6.1.3 KEM-90 DNS3




Fig. 6-3 Outline dimensional of KEM-90 DNS3

Table 6-1

(unit: mm)

| Model | KEM-30 DNS3 | KEM-60 DNS3 | KEM-90 DNS3 |
|-------|-------------|-------------|-------------|
| A | 1870 | 2220 | 3220 |
| B | 1000 | 1325 | 1513 |
| C | 1175 | 1055 | 1095 |
| D | 204 | 234 | 286 |
| E | 200 | 210 | 210 |
| F | 470 | 470 | 470 |



NOTE

After installing the spring damper, the total height of the unit will increase by 135mm or so.

6.2 Requirements of installation space of the unit

- To ensure adequate air flow entering the condenser, the influence of descending air flow caused by the high-rise buildings around upon the unit should be taken into account when installing the unit.
- If the unit is installed where the flowing speed of air is high, such as on the exposed roof, the measures including sunk fence and Persian blinds can be taken, to prevent the turbulent flow from disturbing the air entering the unit. If the unit needs to be provided with sunk fence, the height of the latter should not be more than that of the former; if Persian blinds are required, the total loss of static pressure should be less than the static pressure outside the fan. The space between the unit and sunk fence or Persian blinds should also meet the requirement of the minimum installation space of the unit.
- If the unit needs to operate in winter, and the installation site may be covered by snow, the unit should be located higher than the snow surface, to ensure that air flows through the coils smoothly.
- To avoid back flow of the air in the condenser and operational faults of the unit, the parallel installation of multiple Modular units can follow the direction and distance as shown in Fig. 6-4, Fig. 6-5 and Table 6-2.




Fig. 6-4 Single unit installation




Fig. 6-5 Multiple units installation

Table 6-2 (unit: mm)

| Installation space | |
|--------------------|-------|
| A | ≥800 |
| B | ≥2000 |
| C | ≥2000 |
| D | ≥800 |
| E | ≥800 |
| F | ≥1100 |
| G | ≥6000 |

6.3 Installation foundation

(unit: mm)

6.3.1 Base structure

Outdoor unit base structure design should take account of the following considerations:

- A solid base prevents excess vibration and noise. Outdoor unit bases should be constructed on solid ground or on structures of sufficient strength to support the units' weight.
- Bases should be at least 200mm high to provide sufficient access for installation of piping. Snow protection should also be considered for the base height.
- Either steel or concrete bases may be suitable.
- A typical concrete base design is shown in Fig. 6-6. A typical concrete specification is 1 part cement, 2 parts sand and 4 parts crushed stone with steel reinforcing bar. The edges of the base should be chamfered.
- To ensure that all contact points are equally secure, bases should be completely level. Base design should ensure that the points on the units' bases designed for weight-bearing support are fully supported.




Fig. 6-6 Front view of base structure




Fig. 6-7 Top view of schematic diagram of installation dimension of KEM-30 DNS3

(unit: mm)




Fig. 6-8 Top view of schematic diagram of installation dimension of KEM-60 DNS3

(unit: mm)




Fig. 6-9 Top view of schematic diagram of installation dimension of KEM-90 DNS3

6.3.2 Location drawing of installation foundation of the unit

- The unit should be located on the level foundation, the ground floor or the roof which can bear operating weight of the unit and the weight of maintenance personnel. Refer to Table 12-1 (Table of applicable models and parameters) for operating weight.
- If the unit is located so high that it is inconvenient for maintenance personnel to conduct maintenance, the suitable scaffold can be provided around the unit.
- The scaffold must be able to bear the weight of maintenance personnel and maintenance facilities.
- The bottom frame of the unit is not allowed to be embedded into the concrete of installation foundation.
- A drainage ditch should be provided to allow drainage of condensate that may form on the heat exchangers when the units are running in heating mode. The drainage should ensure that condensate is directed away from roadways and footpaths, especially in locations where the climate is such that condensate may freeze.

6.4 Installation of damping devices

6.4.1 Damping devices

By means of the installation holes on the steel frame of the unit base, the unit can be fastened on the foundation through the spring damper. See Fig.6-7,6-8,6-9 (Schematic diagram of installation dimension of the unit) for details about center distance of the installation holes. The damper does not go with the unit, and the user can select the damper according to the relevant requirements. When the unit is installed on the high roof or the area sensitive to vibration, please consult the relevant persons before selecting the damper.

6.4.2 Installation steps of the damper

Step 1. Make sure that the flatness of the concrete foundation is within $\pm 3\text{mm}$, and then place the unit on the cushion block.

Step 2. Raise the unit to the height suitable for installation of the damping device.

Step 3. Remove the clamp nuts of the damper. Place the unit on the damper, and align the fixing bolt holes of the damper with the fixing holes on the unit base.

Step 4. Return the clamp nuts of the damper to the fixing holes on the unit base, and tighten them into the damper.

Step 5. Adjust the operational height of the damper base, and screw down the leveling bolts. Tighten the bolts by one circle to ensure equal height adjustment variance of the damper.

Step 6. The lock bolts can be tightened after the correct operational height is reached.



NOTE

It is recommended that the damper should be fastened on the foundation with the provided holes. After the unit is placed on the foundation, the damper connected with the unit should not be moved, and the central clamp nut is not allowed to be tightened before the damper sustains load.




Fig. 6-10 Installation of the damper

6.5 Installation of device to prevent snow build-up and strong breeze

When installing an air-cooled heat pump chiller in a place with heavy snow, it is necessary to take snow protection measures to ensure trouble-free operation of the equipment.

Otherwise, accumulated snow will block the air flow and may cause equipment problems.




Fig. 6-11 Types of problems caused by snow

6.5.1 Measures used to prevent problems caused by snow

a. Measures to prevent build-up of snow

The base height should be at least the same as the predicted snow depth in the local area.




Fig. 6-12 Snow prevention base height

b. Lightning protection and snow protection measures

Check the installation site thoroughly; do not install the equipment under awnings or trees or a place where snow is piled up.

6.5.2 Precautions for designing a snow cover


a. To ensure a sufficient air flow required by the air-cooled heat pump chiller, design a protective cover to make the dust resistance $1 \text{ mm H}_2\text{O}$ or less lower than the allowable external static pressure of air-cooled heat pump chiller.

b. The protective cover must be strong enough to withstand the snow weight and the pressure caused by strong wind and typhoon.

c. The protective cover must not cause short circuit of air discharge and suction.

7. CONNECTION DRAWING OF PIPELINE SYSTEM

This is the water system of standard module.



| Symbol explanation | | | | |
|--------------------|----------------|------------------|---------------|---------------------------|
| Stop valve | Pressure gauge | Flexible joint | Gate valve | Automatic discharge valve |
| Y-shaped filter | Thermometer | Circulating pump | one-way valve | |

Fig.7-1 Connection drawing of pipeline system



NOTE

The ratio of the two - way valves on the terminal shall not exceed 50 percent.

8. OVERVIEW OF THE UNIT

8.1 Main parts of the units




Fig. 8-1 Main parts of KEM-30 DNS3




Fig. 8-2 Main parts of KEM-60 DNS3




Fig. 8-3 Main parts of KEM-90 DNS3

| NO. | 1 | 2 | 3 | 4 | 5 | 6 | 7 |
|------|------------|--------------|----------------------|------------|------------|-----------|-------------|
| NAME | Air outlet | Top cover | Electric control box | Compressor | Evaporator | Condenser | Water inlet |
| NO. | 8 | 9 | 10 | | | | |
| NAME | Air inlet | Water outlet | wire controller | | | | |

8.2 Opening the unit

By means of a detachable service panel, the maintenance personnel can easily access the interior components of the unit.




Fig. 8-4 Doors of KEM-30 DNS3




Fig. 8-5 Doors of KEM-60 DNS3




Fig. 8-6 Doors of KEM-90 DNS3

Door 1 give access to the compartment of water pipes and water side heat exchanger.
Door 2/3/4 give access to the refrigerating system components and electrical parts.

8.3 System diagram

8.3.1 Diagram of KEM-30 DNS3

Fig.8-7 is the function diagram of the KEM-30 DNS3.




Fig.8-7 KEM-30 DNS3 function diagram

Table 8-1

| Legend | | | |
|--------|---|----|--|
| 1 | DC inverter compressor | 21 | System pressure sensor |
| 2 | Crankcase heater | 22 | Safety valve |
| 3 | DC inverter compressor discharge temperature sensor 1 | 23 | Vapor-liquid separator |
| 4 | DC inverter compressor discharge temperature sensor 2 | 24 | Pressure gauge joint (low pressure side) |
| 5 | Discharge temperature control switch | 25 | Suction temperature sensor |
| 6 | High pressure switch | 26 | Filter |
| 7 | Pressure gauge joint (high pressure side) | 27 | Capillary |
| 8 | Oil separator | 28 | Fast oil return solenoid valve |
| 9 | 4-way-valve | 29 | Low pressure switch |
| 10 | DC fan | 30 | Filter |
| 11 | Condenser | 31 | Capillary |
| 12 | Coil outlet temperature sensor | 32 | Outdoor ambient temperature sensor |
| 13 | Coil final outlet temperature sensor | 33 | Unit water inlet temperature sensor |
| 14 | Filter | 34 | Safety valve |
| 15 | Electronic expansion valve | 35 | Air purge valve |
| 16 | Filter | 36 | Unit water outlet temperature sensor |
| 17 | High pressure tank | 37 | Water flow switch |
| 18 | Antifreeze heater of plate heat exchanger | 38 | Manual water drain valve |
| 19 | Water side antifreeze temperature sensor 2 | 39 | Total outlet water temperature sensor |
| 20 | Water side antifreeze temperature sensor 1 | 40 | Plate heat exchanger |

8.3.2 diagram of KEM-60 DNS3

Fig.8-8 is the function diagram of the KEM-60 DNS3.




Fig.8-8 KEM-60 DNS3 function diagram

Table 8-2

| Legend | | | |
|--------|---|----|--|
| 1 | Dc inverter compressor 1 | 25 | High pressure tank |
| 2 | Dc inverter compressor 2 | 26 | Antifreeze heater of plate heat exchanger |
| 3 | Crankcase heater 1 | 27 | Water side antifreeze temperature sensor 2 |
| 4 | Crankcase heater 2 | 28 | Water side antifreeze temperature sensor 1 |
| 5 | Dc inverter compressor discharge temperature sensor 1 | 29 | System pressure sensor |
| 6 | Dc inverter compressor discharge temperature sensor 2 | 30 | Pressure gauge joint (low pressure side) |
| 7 | Discharge temperature control switch 1 | 31 | Safety valve |
| 8 | Discharge temperature control switch 2 | 32 | Vapor-liquid separator |
| 9 | One-way valve 1 | 33 | Suction temperature sensor |
| 10 | One-way valve 2 | 34 | Low pressure switch |
| 11 | Pressure gauge joint (high pressure side) | 35 | Filter |
| 12 | High pressure switch | 36 | Capillary |
| 13 | Oil separator | 37 | Fast oil return solenoid valve |
| 14 | 4-way valve | 38 | Filter |
| 15 | Dc fan 1 | 39 | Capillary |
| 16 | Dc fan 2 | 40 | Outdoor ambient temperature sensor |
| 17 | Condenser | 41 | Unit water inlet temperature sensor |
| 18 | Coil outlet temperature sensor | 42 | Safety valve |
| 19 | Coil final outlet temperature sensor | 43 | Air purge valve |
| 20 | Filter | 44 | Unit water outlet temperature sensor |
| 21 | Electronic expansion valve | 45 | Water flow switch |
| 22 | One-way valve 3 | 46 | Total outlet water temperature sensor |
| 23 | Capillary | 47 | Manual water drain valve |
| 24 | Filter | 48 | Plate heat exchanger |

8.3.3 diagram of KEM-90 DNS3

Fig.8-9 is the function diagram of the KEM-90 DNS3.




Fig.8-9 KEM-90 DNS3 function diagram

Table 8-3

| Legend | | | |
|--------|--|----|--|
| 1 | DC inverter compressor 1 | 31 | Unit for cooling electronic control board |
| 2 | DC inverter compressor 2 | 32 | Liquid side bypass solenoid valve |
| 3 | Crankcase heater 1 | 33 | One-way valve 4 |
| 4 | Crankcase heater 2 | 34 | Electronic expansion valve 2 |
| 5 | Enhanced vapor injection solenoid valve 1 | 35 | One-way valve 5 |
| 6 | Enhanced vapor injection solenoid valve 2 | 36 | Filter |
| 7 | Discharge temperature control switch 1 | 37 | High pressure tank |
| 8 | Discharge temperature control switch 2 | 38 | Antifreeze heater of plate heat exchanger |
| 9 | DC inverter compressor discharge temperature sensor 1 | 39 | Water side antifreeze temperature sensor 2 |
| 10 | DC inverter compressor discharge temperature sensor 2 | 40 | Water side antifreeze temperature sensor 1 |
| 11 | One-way valve 1 | 41 | System pressure sensor |
| 12 | One-way valve 2 | 42 | Safety valve |
| 13 | High pressure switch | 43 | Vapor-liquid separator |
| 14 | Pressure gauge joint (high pressure side) | 44 | Pressure gauge joint (low pressure side) |
| 15 | Oil separator | 45 | Low pressure switch |
| 16 | 4-way valve | 46 | Suction temperature sensor |
| 17 | DC fan 1 | 47 | Filter |
| 18 | DC fan 2 | 48 | Capillary |
| 19 | DC fan 3 | 49 | Fast oil return solenoid valve |
| 20 | Condenser | 50 | Filter |
| 21 | Coil outlet temperature sensor | 51 | Capillary |
| 22 | Coil final outlet temperature sensor | 52 | Outdoor ambient temperature sensor |
| 23 | Filter | 53 | Unit water inlet temperature sensor |
| 24 | One-way valve 3 | 54 | Safety valve |
| 25 | Electronic expansion valve 1 | 55 | Air purge valve |
| 26 | Economizer | 56 | Unit water outlet temperature sensor |
| 27 | EVI Electronic expansion valve 3 | 57 | Total outlet water temperature sensor |
| 28 | Refrigerant inlet temperature of evi plate heat exchanger | 58 | Water flow switch |
| 29 | Refrigerant outlet temperature of evi plate heat exchanger | 59 | Manual water drain valve |
| 30 | Multifunctional solenoid valve | 60 | Plate heat exchanger |

8.4 Outdoor unit PCB

MAIN PCB

Label descriptions are given in Table 8-4




Fig. 8-11 Main PCB of KEM-90 DNS3

Table 8-4

| No. | Content |
|-----|--|
| 1 | CN1: Pump 1 connection |
| 2 | CN30: Power sequence detection connection |
| 3 | S5: DIP switches |
| 4 | CN72: Power supply to user interface |
| 5 | ENC2: DIP switch for capacity selection |
| 6 | ENC1: DIP switch for address of outdoor units |
| 7 | DSP1: Digital display |
| 8 | FUS1:Fuse |
| 9 | CN43: Power input |
| 10 | CN12_1, CN12_2: Solenoid valve (SV4) drive ports |
| 11 | IC25: Main control chip |
| 12 | CN64: Debug port |
| 13 | CN6: Four-way valve drive port |
| 14 | CN5, CN5_1: Water side heat exchanger heaters connection |
| 15 | CN4, CN4_1: Water flow switch heaters connection |
| 16 | CN3, CN3_1: Compressor crankcase heater connections |
| 17 | CN52, CN53: Fan inverter module communication ports |

| | |
|----|---|
| 18 | CN50, CN51: Compressor inverter module communication ports |
| 19 | CN55: EXV drive port |
| 20 | CN60, CN71: Wired controller communication ports |
| 21 | CN24: Outdoor ambient temperature sensor and air side refrigerant outlet temperature sensor connections |
| 22 | CN69: Water side heat exchanger ant-freezing temperature sensor 1, coil final outlet temperature, discharge temperature sensor 2 and discharge temperature sensor 1 connections. |
| 23 | CN31: Air suction temperature sensor, water side heat exchanger anti-freezing temperature sensor 2, water side heat exchanger water outlet temperature sensor, water side heat exchanger water inlet temperature sensor and combined water outlet temperature sensor connections. |
| 24 | CN40: System pressure sensor connection |
| 25 | CN41, CN42: Inverter module temperature 1 and Inverter module temperature sensor 2 connections |
| 26 | CN62: AC indicator A and AC indicator B connections |
| 27 | CN65: Low pressure switch connection |
| 28 | CN47: High pressure switch and discharge temperature switch(es) connections |
| 29 | CN58, CN59: AC filter board communication ports |
| 30 | CN44: Water flow switch, remote function of on/off and cool/heat connections |
| 31 | IC10: EEPROM |
| 32 | CN21: Remote alarm connection |
| 33 | CN19_N: Electric auxiliary heater N line connection |
| 34 | CN19_L: Electric auxiliary heater N line connection |

Label descriptions are given in Table 8-5




Fig. 8-11 Main PCB of KEM-90 DNS3

Table 8-5

| No. | Detail information |
|-----|---|
| 1 | <p>CN30: Input of three-phase four-wire power supply (fault code E1) Input of transformer, 220-240V AC current. (only valid for the main unit) Three phases L1, L2 and L3 of power supply should exist simultaneously, and the difference of phase angle should be 120° among them. If the conditions are not met, fault of phase sequence or phase lack may occur, and fault code will be displayed. When the power supply returns to normal condition, fault is removed. Attention: phase lack and phase dislocation of power supply are detected only in the early period after the power supply is connected, and they are not detected while the unit is in operation.</p> |
| 2 | CN12: Quick return oil solenoid valve |
| 3 | CN80: Injection solenoid valve of compressor system B |
| 4 | CN47: Injection solenoid valve of compressor system A |
| 5 | CN5: Water side heat exchanger heaters connection |
| 6 | CN40: Multi-function solenoid valve |
| 7 | CN13: Electric of water side heat exchanger heaters connection |
| 8 | CN41: Liquid bypass solenoid valve |
| 9 | CN42: Crankcase heater |
| 10 | CN6: Four-way valve |
| 11 | CN43: Crankcase heater |
| 12 | CN4/CN11: Electric heater of water flow switch |
| 13 | CN14: Three-way valve(hot-water valve) |
| 14 | <p>CN83: Pump 1) After receiving start-up instruction, the pump will be started up instantly, and will maintain start-up state always in the process of operation. 2) In case of refrigerating or heating shutdown, the pump will be shut down 2 minutes after all modules stop operating. 3) In case of shutdown under the pump mode, the pump can be directly shut down.</p> |
| 15 | <p>CN83: COMP-STATE, connect with an ac light to indicate the state of the compressor Attention: the control port value of the pump actually detected is ON/OFF but not 220-230V control power supply, so special attention should be paid when installing the light.</p> |

| No. | Detail information |
|-----|--|
| 16 | CN2: HEAT1. Pipeline Auxiliary Heater Attention: the control port value of the pump actually detected is ON/OFF but not 220-230V control power supply, so special attention should be paid when installing the pipeline auxiliary heater. |
| 17 | CN85: The alarm signal output of the unit(ON/OFF signal) Attention: the control port value of the pump actually detected is ON/OFF but not 220-230V control power supply, so special attention should be paid when installing the alarm signal output. |
| 18 | Discharge temperature switch protection (protection code P0, prevent the compressor from over temperature 115°C) |
| 19 | CN71: System electronic expansion valve2. Used for cooling. |
| 20 | CN72: EVI electronic expansion valve. Used for EVI. |
| 21 | CN70: System electronic expansion valve1. Used for heating. |
| 22 | CN60: Outdoor units communication or HMI communication port |
| 23 | CN61: Outdoor units communication or HMI communication port |
| 24 | CN64: Fan inverter module communication ports |
| 25 | CN65: Compressor inverter module communication ports |
| 26 | CN300: Program burn in port (WizPro200RS programming device). |
| 27 | IC10: EEPROM chip |
| 28 | CN1: temperature sensors input port. T4: outdoor ambient temperature sensor T3A/T3B: pipe temperature sensor of the condenser T5: water tank temperature sensor T6A: Refrigerant inlet temperature of EVI plate heat exchanger T6B: Refrigerant inlet temperature of EVI plate heat exchanger |
| 29 | CN16: System pressure sensor |
| 30 | CN31: Temperature sensors input port Th: System suction temperature sensor Taf2: Water side antifreeze temperature sensor Two: Unit water outlet temperature sensor Twi: Unit water inlet temperature sensor Tw: Total water outlet temperature sensor when several units are connected in parallel |
| 31 | CN3: Module 1 temperature sensor |
| 32 | CN10: Module 2 temperature sensor |
| 33 | CN15: Detection of current of the compressor system input port INV1: Detection of current of the compressor A INV2: Detection of current of the compressor B |

| No. | Detail information |
|-----|--|
| 34 | CN69: Temperature sensors input port Tp1: DC inverter compressor 1 discharge temperature sensor Tp2: DC inverter compressor 2 discharge temperature sensor Tz/7: coil final outlet temperature sensor Taf1: Water side antifreeze temperature |
| 35 | CN19: Low voltage protection switch. (Protection code P1) |
| 36 | CN91: Three-phase protector output switch. (Protection code E8) |
| 37 | CN58: Fan relay driver port. |
| 38 | CN8: Remote function of cool/heat signal |
| 39 | CN8: Remote function of on/off signal |
| 40 | CN8: Water flow switch signal |
| 41 | SW3: Up button a) Select different menus when enter menu selection. b) For spot inspection in conditions. SW4: Down button a) Select different menus when enter menu selection. b) For spot inspection in conditions. SW5: Menu button Press to enter menu selection, short press to return to the previous menu. SW6: OK button Enter the submenu or confirm the function selected by short pressing. |
| 42 | Digital tube 1) In case of stand-by, the address of the module is displayed; 2) In case of normal operation, 10. is displayed (10 is followed by dot). 3) In case of fault or protection, fault code or protection code is displayed. |
| 43 | S5: Dip switch S5-3: Normal control, valid for S5-3 OFF (factory default). Remote control, valid for S5-3 ON. |
| 44 | CN7: Target water temperature switching port. |
| 45 | ENC2: POWER DIP switch for capacity selection, 2 by default |
| 46 | CN74: The power supply port of the HMI. (DC9V) |
| 47 | ENC4: NET_ADDRESS DIP switch 0-F of outdoor unit network address is enabled, which represent address 0-15 |
| 48 | S12: Dip switch S12-1: Valid for S12-1 ON (factory default). S12-2: Single water pump controll, valid for S12-2 OFF (factory default) Multiple water pumps controll, valid for S12-2 ON. S12-3: Normal cooling mode, valid for S12-3 OFF (factory default). Low temperature cooling, valid for S12-3 ON. |



CAUTION

a. Faults

When the main unit suffers faults, the main unit stops operating, and all other units also stop running;
When the subordinate unit suffers faults, only the unit stops operating, and other units are not affected.

b. Protection

When the main unit is under protection, only the unit stops operating, and other units keep running;
When the subordinate unit is under protection, only the unit stops operating, and other units are not affected.

8.5 Electric wiring

8.5.1 Electric wiring

CAUTION

1. The air-conditioner should apply special power supply, whose voltage should conform to rated voltage.
2. Wiring construction must be conducted by the professional technicians according to the labeling on the circuit diagram.
3. The power wire and the grounding wire must be connected the suitable terminals.
4. The power wire and the grounding wire must be fasten up by suitable tools.
5. The terminals connected the power wire and the grounding wire must be fully fastened and regularly checked, in case to become flexible.
6. Only use the electric components specified by our company, and require installation and technical services from the manufacturer or authorized dealer. If wiring connection fails to conform to electric installation norm, failure of the controller, electronic shock, and so on may be caused.
7. The connected fixed wires must be equipped with full switching-off devices with at least 3mm contact separation.
8. Set leakage protective devices according to the requirements of national technical standard about electric equipment.
9. After completing all wiring construction, conduct careful check before connecting the power supply.
10. Please carefully read the labels on the electric cabinet.
11. The user's attempt to repair the controller is prohibited, since improper repair may cause electric shock, damages to the controller, and so on. If the user has any requirement of repair, please contact the maintenance center.
12. The power cord type designation is H07RN-F.

8.5.2 KEM-30 DNS3 and KEM-60 DNS3

DIP switch, buttons and digital display positions of units.




Fig. 8-12 Display positions

8.5.3 KEM-90 DNS3

DIP switch, buttons and digital display positions of units.




Fig. 8-13 Display positions







8.5.4 DIP switch instructions

The definitions for DIP switch of KEM-30 DNS3 and KEM-60 DNS3 are different from those of KEM-90 DNS3. See Table 8-6 for DIP switch instructions of KEM-30 DNS3 and KEM-60 DNS3, and Table 8-7 for KEM-90 DNS3.

Table 8-6 KEM-30 DNS3 and KEM-60 DNS3

| | | | |
|------|--|-----|---|
| ENC1 | | 0-F | 0-F valid for unit address setting on the DIP switches 0 indicates the master unit and 1-F the auxiliary units (parallel connection) (0 by default) |
| ENC2 | | 0-5 | DIP switch for capacity selection (KEM-30 DNS3 defaults 2) (KEM-60 DNS3 defaults 5) |
| S5-1 | | OFF | Normal cooling mode Valid for S5-1 OFF(factory default) |
| | | ON | Low-temperature cooling mode Valid for S5-1 ON |
| S5-3 | | OFF | Single water pump control Valid for S5-3 OFF(factory default) |
| | | ON | Multiple water pumps control Valid for S5-3 ON |
| S5-4 | | OFF | Normal control Valid for S5-4 OFF(factory default) |
| | | ON | Remote control valid for S5-4 ON |

Table 8-7 KEM-90 DNS3

| | | | |
|-------|--|-----|--|
| ENC2 |  | 2 | DIP switch for capacity selection (KEM-90 DNS3 defaults 2) |
| ENC4 |  | 0-F | 0-F valid for unit address setting on the DIP switches 0 indicates the master unit and 1-F the auxiliary units (parallel connection) (0 by default) |
| S5-3 |  | OFF | Normal control Valid for S5-3 OFF(factory default) |
| | | ON | Remote control valid for S5-3 ON |
| S12-1 |  | ON | valid for S2-1 ON (factory default) |
| S12-2 |  | OFF | Single water pump control Valid for S12-2 OFF(factory default) |
| | | ON | Multiple water pumps control Valid for S12-2 ON |
| S12-3 |  | OFF | Normal cooling mode Valid for S12-3 OFF(factory default) |
| | | ON | Low-temperature cooling mode Valid for S12-3 ON |

8.5.5 Button instructions

The instructions for buttons of KEM-30 DNS3, KEM-60 DNS3 and KEM-90 DNS3 are the same. See the instructions below:

MENU button:

Press the button for 5s to enter menu selection.

Short press it to return the previous menu.

OK button:

Short press the button to enter the submenu or confirm the function selected.

UP button/ DOWN button:

a) Select different menus when enter menu selection

b) Used for spot checks in other circumstance

8.5.6 Menu selection instructions

The menu selection instructions for KEM-30 DNS3, KEM-60 DNS3 and KEM-90 DNS3 are the same. See the instructions below:

Press the menu button to enter menu selection and display n10 (it exits if no button is pressed in 10 seconds). Use the up button/down button to select different level-1 menus (n11~nd1).

Press the confirmation button to enter the level-2 menu and display nx1 (x indicates 1~d). After entering the level-2 menu, use the up button/down button to select different level-2 menus and display nxy (x indicates the level-1 menu No.; y indicates the level-2 menu No.) Use the confirmation button to confirm the specific menu command.

8.5.7 Menu types instructions

Menu type function is not available for KEM-90 DNS3. For menu types instructions of KEM-30 DNS3 and KEM-60 DNS3, see Table 8-8.

Table 8-8 KEM-30 DNS3 and KEM-60 DNS3

| MENU | FUNCTION | NOTE |
|------|-----------------------|----------------------------------|
| n40 | Time 1 of silent mode | 6/10h (factory default) |
| n41 | Time 2 of silent mode | 6/12h |
| n42 | Time 3 of silent mode | 8/10h |
| n43 | Time 4 of silent mode | 8/12h |
| n51 | Silent mode 1 | Silent mode |
| n52 | Silent mode 2 | Super silent mode |
| n53 | Silent mode 3 | No silent mode (factory default) |

8.5.8 Query display

Spot check the parameters using UP/DOWN buttons in non-menu mode. The instructions for spot check sequence displaying of KEM-30 DNS3 and KEM-60 DNS3 are different from those of KEM-90 DNS3. See Table 8-9 for spot check sequence instructions of KEM-30 DNS3 and KEM-60 DNS3, and Table 8-10 for KEM-90 DNS3.

Table 8-9 KEM-30 DNS3 and KEM-60 DNS3

| Digital tube display | Spot inspection item |
|----------------------|--|
| | Standby: Outdoor units address (L88) + number of on-line units(R88) On: display frequency Defrosting: dF and operating frequency flash alternately at 1s intervals In case of Pb protection, Pb and operating frequency flash alternately at 1s intervals |
| 0.xx | Outdoor units address |
| 1.xx | 30kW displays 12, 60kW displays 24 |
| 2.xx | Number of units (Main unit included) |
| 3.xx | 3 displayed |
| 4.xx | Operation modes (8 OFF, 0 Standby, 1 Cooling, and 2 Heating) |
| 5.xx | Fan Speed |
| 6.xx | 0 displayed |
| 7.xx | T3 |
| 8.xx | T4 |
| 9.xx | T5(reserved) |
| 10.xx | Taf1 |
| 11.xx | Taf2 |
| 12.xx | Tw |
| t.xxx | Twi |
| 14.xx | Two |
| 15.xx | Tz/7 |
| 16.xx | -- |
| 17.xx | Tp1 |
| 18.xx | Tp2 |
| 19.xx | Tf1 |
| 20.xx | Tf2 |
| 21.xx | Discharge superheat degree Tdsh |
| 22.xx | Current of compressor A |
| 23.xx | Current of Compressor B |
| 24.xx | -- |
| 25.xx | Electronic expansion valve 1 opening (/4) |
| 26.xx | Electronic expansion valve 2 opening (/4) |
| 27.xx | High pressure |
| L.xxx | Low pressure |
| 29.xx | Suction superheat |
| 30.xx | Suction temperature |
| 31.xx | Silent mode selection |
| 32.xx | Static pressure selection |
| 33.xx | -- |
| 34.xx | -- |
| 35.xx | Last fault |
| 36.xx | Frequency limiting No. (0: No frequency limiting; 1: Frequency limiting of T4; 2: Frequency limiting of Tp1; 3: Frequency limiting of Tp2; 4: Frequency limiting of Tz/7; 5: Frequency limiting of TzB; 6: Frequency limiting of Tf1; 7: Frequency limiting of Tf2; 8: Frequency limiting of high pressure H-YL; 9: Frequency limiting of compressor current ; 10: Frequency limiting of voltage |
| 37.xx | Defrosting process status (the first digit: T4 selection solution; the second digit: scheme's range; the third and fourth digits as a whole indicates the defrosting time) |
| 38.xx | EEPROM error: 1 means error, and 0 means no error |
| 39.xx | Defrosting solution |
| 40.xx | Initial frequency |
| 41.xx | Tc (+30°C) / Te(+25°C) |
| 42.xx | Number of unit those on working |
| 43.xx | Software version No. |
| 44.xx | ---- |

Table 8-10 KEM-90 DNS3

| Digital tube display | Sport Check Item |
|----------------------|---|
| | Standby: Outdoor units address (88 on the left)+ number of online units (88 on the right) On: display frequency Defrosting: dF dF |
| 0.xx | Outdoor units address |
| 1.xx | 90kw displays 90 |
| 2.xx | Number of online units (main unit included) |
| 3.xx | 1 displayed |
| 4.xx | Operation mode (8 - Off, 1 - Cool, 2 -Heat) |
| 5.xx | Fan speed (0 - 35) |
| 6.xx | 0 displayed |
| 7.xx | T3 |
| 8.xx | T4 |
| 9.xx | T5 (reserved) |
| 10.xx | Taf1 |
| 11.xx | Taf2 |
| 12.xx | Tw |
| 13.xx | Twi |
| 14.xx | Two |
| 15.xx | Tz/7 |
| 16.xx | -- |
| 17.xx | Tp1 |
| 18.xx | Tp2 |
| 19.xx | Tf1 |
| 20.xx | Tf2 |
| 21.xx | Discharge superheat Tdsh |
| 22.xx | Current of compressorA |
| 23.xx | Current of compressor B |
| 24.xx | -- |
| 25.xx | Electronic expansion valve A opening (/20) |
| 26.xx | Electronic expansion valve B opening (/20) |
| 27.xx | Electronic expansion valve C opening (/4) |
| 28.xx | High pressure (Heating mode) |
| L.xxx | Low pressure |
| 30.xx | Suction superheat |
| 31.xx | Suction temperature |
| 32.xx | The first digital tube from the right: Silence selection: 0 – Night silent; 1 - Silent; 2 - Super silent; 3 - No silence (by default) The second digital tube from the right: Silence time selection (0-3) values depend on the parameters of the wired controller |

| | |
|-------|--|
| 33.xx | Static pressure selection (0 static pressure by default) |
| 34.xx | -- |
| 35.xx | -- |
| 36.xx | Frequency limiting No. (0: No frequency limiting; 1: T4 Frequency limiting; 2: Discharge frequency limiting; 3: Frequency limiting of Tz total cold outlet; 4: Frequency limiting of module temperature; 5: Pressure frequency limiting; 6: Current frequency limiting; 7: Voltage frequency limiting) |
| 37.xx | Defrosting process state (the first digit: T4 selection solution; the second digit: interval in the solution; the third digit and fourth digit determine the defrosting timer time) |
| 38.xx | EEPROM error: 1 means error, and 0 means no error |
| 39.xx | Defrosting solution |
| 40.xx | Initial frequency |
| 41.xx | Tc (Saturation temperature corresponding to the high pressure in heating mode) |
| 42.xx | Te (Saturation temperature corresponding to the low pressure in cooling mode) |
| 43.xx | T6A |
| 44.xx | T6B |
| 45.xx | Software version No. |
| 46.xx | Last malfunction |
| 47.xx | ---- |

- c. It is advisable to use 3-core shielded cables for unit to minimize interference. Do not use the unshielded multicore conductor cables.




Fig. 8-14-3 Electrical wiring precaution (c)

- d. Power wiring must be entrusted to professionals with electrician qualification.




Fig. 8-14-4 Electrical wiring precaution (d)

8.5.9 Electrical wiring precautions

- a. On-site wiring, parts and materials must comply with the local and national regulations as well as relevant national electrical standards.




Fig. 8-14-1 Electrical wiring precaution (a)

- b. Copper core wires must be used




Fig. 8-14-2 Electrical wiring precaution (b)

8.5.10 Power supply specification

Table 8-11 Selection of power wire diameter and manual switch

| Model | Item | Outdoor power supply | | | |
|-------------|------|----------------------|---------------|--------|----------------------|
| | | Power supply | Manual switch | Fuses | Wiring (<20m) |
| KEM-30 DNS3 | | 380-415V 3N~50Hz | 50A | 3X36A | 10mm ² x5 |
| KEM-60 DNS3 | | 380-415V 3N~50Hz | 100A | 3X63A | 16mm ² x5 |
| KEM-90 DNS3 | | 380-415V 3N~50Hz | 125A | 3X100A | 25mm ² x5 |




NOTE

See the table above for power wire diameter and length when the voltage drop at the power wiring point is within 2%. If the wire length exceeds the value specified in the table or the voltage drop is beyond the limit, the power wire diameter should be larger in accordance with the relevant regulations.

8.5.11 Requirements for power supply wiring

○ Correct



✗ Wrong




Fig. 8-15 Requirements of power supply wiring




NOTE

Do not connect the grounding wire of the lightning arrester to the unit shell. The grounding wire of the lightning arrester and the power supply grounding wire must be configured separately.

8.5.12 Requirements for power cord connection

○ Correct



✗ Wrong




Fig. 8-16 Requirements for power cord connection



NOTE

Please use the round-type terminal with correct specifications to connect the power cord.

8.5.13 Function of terminals

As shown in the figure below, the wired controller signal wire and unit communication signal wire for KEM-30 DNS3 and KEM-60 DNS3 are both connected to the terminal block inside the electric control box. For specific wiring, see chapter 8.5.18 (I & II).




Fig. 8-17 Function of terminals of KEM-30 DNS3 and KEM-60 DNS3

As shown in the figure below, the unit communication signal wire for KEM-90 DNS3 is connected to the terminal block XT2 at 5(X), 6(Y) and 7(E), and the wired controller signal wire is connected at 8(X), 9(Y) and 10(E) inside the electric control box. For specific wiring, see chapter 8.5.18 (III).




Fig. 8-18 Function of terminals of KEM-90 DNS3

When the water pump and auxiliary heater are added to KEM-30 DNS3 and KEM-60 DNS3 externally, a 3-phase contactor must be used for control. The model of contactor is subject to the power of water pump and auxiliary heater. The contactor coil is controlled by the main control board. See the figure below for coil wiring. For specific wiring, see chapter 8.5.18 (I & II).




Fig. 8-19 Function of terminals of KEM-30 DNS3 and KEM-60 DNS3 with pump or heater

When the water pump and auxiliary heater are added to KEM-90 DNS3 externally, a 3-phase contactor must be used for control. The model of contactor is subject to the power of water pump and heater power. The contactor coil is controlled by the main control board. See the figure below for coil wiring. For specific wiring, see chapter 8.5.18 (III).




Fig. 8-20 Function of terminals of KEM-90 DNS3 with pump or heater

8.5.14 Wiring of "ON/OFF" weak electric port

The remote function of "ON/OFF" must be set by DIP switch. The remote function of "ON/OFF" is effective when S5-4 for KEM-30 DNS3 and KEM-60 DNS3 or S5-3 for KEM-90 DNS3 is chosen ON, at the same time, the wire controller is out of control. Corresponding parallel connect the "ON/OFF" port of the main unit's electric control box, then, connect the "ON/OFF" signal (provide by user) to the "ON/OFF" port of main unit as follows. The remote function of "ON/OFF" must be DIP switch set.

Wiring method: When KEM-30 DNS3 and KEM-60 DNS3 enable "ON/OFF" control, short the "ON/OFF" ports on the main control board. When KEM-90 DNS3 enables "ON/OFF" control, short the terminal block XT2 at 15 and 24 inside the electric control box.




Fig. 8-21 Wiring of "ON/OFF" weak electric port

If the "ON/OFF" port is effective, the " " icon of the wire controller will be flashing.

8.5.15 Wiring of “HEAT/COOL” weak electric port

The remote function of “ON/OFF” must be set by DIP switch. The remote function of “ON/OFF” and “HEAT/COOL” is effective when S5-4 for KEM-30 DNS3 and KEM-60 DNS3 or S5-3 for KEM-90 DNS3 is chosen ON, at the same time, the wire controller is out of control.

Corresponding parallel connect the “HEAT/COOL” port of the main unit’s electric control box, then, connect the “ON/OFF” signal (provide by user) to the “HEAT/COOL” port of main unit as follows.

Wiring method: When KEM-30 DNS3 and KEM-60 DNS3 enable “HEAT/COOL” control, short the “HEAT/COOL” ports on the main control board.

When KEM-90 DNS3 enables “HEAT/COOL” control, short the terminal block XT2 at 14 and 23 inside the electric control box.




Fig. 8-22 Wiring of “HEAT/ COOL” weak electric port

8.5.16 Wiring of “ALARM” port

Connect the device provided by user to the “ALARM” ports of the module units as follows.




Fig. 8-23 Wiring of “ALARM” port

If the unit is operating unnormally, the ALARM port is closed, otherwise, the ALARM port is not closed.

The ALARM ports for KEM-30 DNS3, KEM-60 DNS3 and KEM-90 DNS3 are on the main control board. See the wiring nameplate for details.

8.5.17 Control system and installation precautions

- Use only shielded wires as control wires. Any other type of wires may produce a signal interference that will cause the units to malfunction.



Fig. 8-24-1 Control system and installation precaution (a)

- The shielding nets at both ends of the shielded wire must be grounded. Alternatively, the shielding nets of all shielded wires are interconnected and then connected to earth through or one metal plate.




Fig. 8-24-2 Control system and installation precaution (b)

- Do not bind the control wire, refrigerant piping and power cord together. When the power cord and control wire are laid parallel, they should be kept at a distance of more than 300 mm to prevent signal source interference.




Fig. 8-24-3 Control system and installation precaution (c)

- Pay attention to the polarity of the control wire when conducting wiring operations.




Fig. 8-24-4 Control system and installation precaution (d)

8.5.18 Wiring instances

If multiple units are connected in parallel, the user needs to set unit address on the DIP switches.

The DIP switch address for units of KEM-30 DNS3 and KEM-60 DNS3 is ENC1 and for unit of KEM-90 DNS3 is ENC4. With 0-F being valid, 0 indicates the main unit and 1-F the auxiliary units. The pump contactor wiring of KEM-90 DNS3 is different with KEM-30 DNS3 and KEM-60 DNS3. The user must be sure to wire as shown in the following figures.




Fig. 8-25 Networking communication schematic of main unit and auxiliary unit of KEM-30 DNS3



NOTE

When the power cord is parallel to the signal wire, make sure that they are enclosed in respective conduits and are kept a reasonable wire spacing. (Distance between the power cord and signal wire: 300 mm if below 10 A, and 500 mm if below 50 A)



CAUTION

In the case of multiple units connection, the HMI of KEM-30 DNS3 and KEM-60 DNS3 can be paralleled with in the same system, while KEM-90 DNS3 can't be.




Fig. 8-27 Networking communication schematic of main unit and auxiliary unit of KEM-90 DNS3



NOTE

When the power cord is parallel to the signal wire, make sure that they are enclosed in respective conduits and are kept a reasonable wire spacing. (Distance between the power cord and signal wire: 300 mm if below 10 A, and 500 mm if below 50 A)



CAUTION

In the case of multiple units connection, the HMI of KEM-30 DNS3 and KEM-60 DNS3 can be paralled with in the same system, while KEM-90 DNS3 can't be.

8.6 Water system installation

8.6.1 Basic requirements of connection of chilled water pipes



CAUTION

- After the unit is in place, chilled water pipes can be laid.
- The relevant installation regulations should be abided with when conducting connection of water pipes.
- The pipelines should be free of any impurity, and all chilled water pipes must conform to local rules and regulations of pipeline engineering.

- a. All chilled water pipelines should be thoroughly flushed, to be free of any impurity, before the unit is operated. Any impurity should not be flushed to or into the heat exchanger.
- b. Water must enter the heat exchanger through the inlet; otherwise the performance of the unit will decline.
- c. The pump installed in the water pipeline system should be equipped with starter. The pump will directly press water into the heat exchanger of the water system.
- d. The pipes and their ports must be independently supported but should not be supported on the unit.
- e. The pipes and their ports of the heat exchanger should be easy to disassemble for operation and cleaning, as well as inspection of port pipes of the evaporator.
- f. The evaporator should be provided with a filter with more than 40 meshes per inch at site. The filter should be installed near to the inlet port as much as possible, and be under heat preservation.
- g. The by-pass pipes and by-pass valves as shown in Fig. 7-1 must be mounted for the heat exchanger, to facilitate cleaning of the outside system of water passage before the unit is adjusted. During maintenance, the water passage of the heat exchanger can be cut off without disturbing other heat exchangers.
- h. The flexible ports should be adopted between the interface of the heat exchanger and on-site pipeline, to reduce transfer of vibration to the building.
- i. To facilitate maintenance, the inlet and outlet pipes should be provided with thermometer or manometer. The unit is not equipped with pressure and temperature instruments, so they need to be purchased by the user.
- j. All low positions of the water system should be provided with drainage ports, to drain water in the evaporator and the system completely; and all high positions should be supplied with discharge valves, to facilitate expelling air from the pipeline. The discharge valves and drainage ports should not be under heat preservation, to facilitate maintenance.
- k. All possible water pipes in the system to be chilled should be under heat preservation, including inlet pipes and flanges of the heat exchanger.
- l. The outdoor chilled water pipelines should be wrapped with an auxiliary heating belt for heat preservation, and the material of the auxiliary heat belt should be PE, EDPM, etc., with thickness of 20mm, to prevent the pipelines from freezing and thus cracking under low temperature. The power supply of the heating belt should be equipped with an independent fuse.

m. When the ambient temperature is lower than 2°C, and the unit will be not used for a long time, water inside the unit should be drained. If the unit is not drained in winter, its power supply should not be cut off, and the fan coils in the water system must be provided with three-way valves, to ensure smooth circulation of the water system when the anti-freezing pump is started up in winter.

n. Total outlet water temperature sensor of main unit must be installed on total outlet water pipe in multi-module combination system.



WARNING

For the water pipeline network including filters and heat exchangers, dreg or dirt may seriously damages the heat exchangers and water pipes.

The installation persons or the users must ensure the quality of chilled water, and de-icing salt mixtures and air should be excluded from the water system, since they may oxidize and corrode steel parts inside the heat exchanger.

8.6.2 Connection mode of pipe

The water inlet and outlet pipes are installed and connected as shown in the following figures. KEM-30 DNS3 model uses screwed connection, while the KEM-60 DNS3 and KEM-90 DNS3 models use hoop connection. For the specifications of the water pipes and screw thread, see the Table 8-12 below.

Table 8-12

| Model | Specifications of Pipe connection | Specifications of water pipe |
|-------------|-----------------------------------|------------------------------|
| KEM-30 DNS3 | Rc 1 1/4 | DN40 |
| KEM-60 DNS3 | 2" | DN50 |
| KEM-90 DNS3 | 2" | DN50 |




Fig. 8-28 Connection mode of KEM-30 DNS3 pipe




Fig. 8-29 Connection mode of KEM-60 DNS3 pipe




Fig. 8-30 Connection mode of KEM-90 DNS3 pipe

8.6.3 Design of the store tank in the system

kW is the unit for cooling capacity and L is the unit for G, water flow in the formula counting the minimum water flow.

Comfortable air conditioner
 $G = \text{cooling capacity} \times 3.5L$

Process cooling
 $G = \text{cooling capacity} \times 7.4L$

In certain occasion (especially in manufacture cooling process), for conforming the system water content requirement, it's necessary to mount a tank equipping with a cut-off baffle at the system to avoid water short-circuit, Please see the following schemes:




Fig. 8-31 Design of the store tank

8.6.4 Minimum water flow

The minimum chilled water flow is shown in the table 8-13. If the system flow is less than the minimum unit flow rate, the evaporator flow can be recirculated, as shown in the diagram.




Fig. 8-32 For minimum water flow rate

8.6.5 Maximum water flow

The maximum chilled water flow is limited by the permitted pressure drop in the evaporator. It is provided in the table 8-13. If the system flow is more than the maximum unit flow rate, bypass the evaporator as shown in the diagram to obtain a lower evaporator flow rate.




Fig. 8-33 For maximum water flow

8.6.6 Minimum and Maximum water flow

Table 8-13 (unit: m³/h)

| Model \ Item | Water flow rate | |
|--------------|-----------------|---------|
| | Minimum | Maximum |
| KEM-30 DNS3 | 3.8 | 6.4 |
| KEM-60 DNS3 | 8.0 | 13.0 |
| KEM-90 DNS3 | 10.2 | 16.5 |

8.6.7 Selection and installation of the pump

8.6.7.1 Select the pump

- Select the water-flow of the pump
The rated water-flow must no less than the unit rated water-flow; in terms of multi-connect the units, that water-flow must no less than total units' rated water-flow.
- Select the lift of the pump.
 $H = h_1 + h_2 + h_3 + h_4$
H: The lift of the pump.
h1: Main unit water resistance.
h2: Pump water resistance.

h3: Water resistance of the longest water-loop distance, includes: pipe resistance, different valve's resistance, flexible pipe resistance, pipe elbow and three-way resistance, two-way resistance or three-way resistance, as well as filter resistance.
H4: the longest terminal resistance.

8.6.7.2 Installation the pump

- The pump should be installed at the water inlet pipe, both of which sides must mount the soft connectors for vibration-proof.
- The backup pump for the system (recommended).
- Units must with a main unit controls (Please see Fig. 8-22 for the controls wiring diagram).

8.6.8 Water quality control

8.6.8.1 Water quality control

When industrial water is used as chilled water, little furring may occur; however, well water or river water, used as chilled water, may cause much sediment, such as furring, sand, and so on. Therefore, well water or river water must be filtered and softened in softening water equipment before flowing into chilled water system. If sand and clay settle in the evaporator, circulation of chilled water may be blocked, and thus leading to freezing accidents; if hardness of chilled water is too high, furring may occur easily, and the devices may be corroded. Therefore, the quality of chilled water should be analyzed before being used, such as PH value, conductivity, concentration of chloride ion, concentration of sulfide ion, and so on.

8.6.8.2 Applicable standard of water quality for the unit

Table 8-14

| | |
|----------------|------------------|
| PH value | 6.8-8.0 |
| Total hardness | <70ppm |
| Conductivity | <200μV/cm (25°C) |
| Sulfide ion | No |
| Chloride ion | <50ppm |
| Ammonia ion | No |
| Sulfate | <50ppm |
| Silicon | <30ppm |
| Iron content | <0.3ppm |
| Sodium ion | No requirement |
| Calcium ion | <50ppm |

8.6.9 Installation of multi-module water system pipeline

Multi-module combination installation involves special design of the unit, so relevant explanation is given as follows.

8.6.9.1 Installation mode of multi-module combination water system pipeline




Fig. 8-34 Installation of multi-module (no more than 16 modules)



CAUTION

KEM-30 DNS3 and KEM-60 DNS3 can be connected in the same water system, while KEM-90 DNS3 can not be connected with other models.

8.6.9.2 Table of diameter parameters of main inlet and outlet pipes

Table 8-15

| Cooling capacity(kW) | Total inlet and outlet water pipe inside nominal diameter |
|----------------------|---|
| $15 \leq Q \leq 30$ | DN40 |
| $30 < Q \leq 90$ | DN50 |
| $90 < Q \leq 130$ | DN65 |
| $130 < Q \leq 210$ | DN80 |
| $210 < Q \leq 325$ | DN100 |
| $325 < Q \leq 510$ | DN125 |
| $510 < Q \leq 740$ | DN150 |
| $740 < Q \leq 1300$ | DN200 |
| $1300 < Q \leq 2080$ | DN250 |



CAUTION

Please pay attention to the following items when installing multiple modules:

- Each module corresponds to an address code which cannot be repeated.
- Main water outlet temperature sensor and auxiliary electric heater are under control of the main module.
- The unit can be started up through the wired controller only after all addresses are set and the aforementioned items are determined. The wired controller is $\leq 500\text{m}$ away from the outdoor unit.

8.6.10 Installation of single or multiple water pumps

8.6.10.1 DIP switch

The choice of DIP switch see Table 8-6 in detail when single or multiple water pumps are installed for KEM-30 DNS3 and KEM-60 DNS3.

The choice of DIP switch see Table 8-7 in detail when single or multiple water pumps are installed for KEM-90 DNS3.

Pay attention to the following problems:

- If the DIP switch is inconsistent, and the error code is FP, the unit is not allowed to operate.
- Only the main unit has the water pump output signal when single water pump installed, auxiliary units has no water pump output signal.
- The water pump control signal is available for both the main unit and auxiliary units when multiple pumps installed.

8.6.10.2 Installation of water pipe system

a. Single water pump

Piping does not require a one-way valve when single water pump is installed, refer to figure as follow.




Fig. 8-35 Installation of single water pump

b. Multiple water pumps

Each unit is required to install a one-way valve when multiple pumps are installed, refer to figure as follow.




Fig. 8-36 Installation of multiple water pump

8.6.10.3 Electric wiring

Only the main unit requires wiring when single water pump installed, auxiliary units do not require wiring. All of the main unit and auxiliary units require wiring when multiple water pumps installed. For specific wiring, see figure 8-19 and 8-20.

9. START-UP AND CONFIGURATION

9.1 Initial start-up at low outdoor ambient temperature

During initial start-up and when water temperature is low, it is important that the water is heated gradually. Failure to do so may result in concrete floors cracking due to rapid temperature change. Please contact the responsible cast concrete building contractor for further details.

To do so, the lowest water flow set temperature can be decreased to a value between 25°C and 35°C by adjusting the FOR SERVICEMAN. Refer to "FOR SERVICEMAN/special function/preheating for floor"

9.2 Points for attention prior to trial run

- After the water system pipeline is flushed several times, please make sure that the purity of water meets the requirements; the system is re-filled with water and drained, and the pump is started up, then make sure that water flow and the pressure at the outlet meet the requirements.
- The unit is connected to the main power 12 hours before being started up, to supply power to the heating belt and pre-heat the compressor. Inadequate pre-heating may cause damages to the compressor.
- Setting of the wired controller. See details of the manual concerning setting contents of the controller, including such basic settings as refrigerating and heating mode, manual adjustment and automatic adjustment mode and pump mode. Under normal circumstances, the parameters are set around standard operating conditions for trial run, and extreme working conditions should be prevented as much as possible.

10. FINAL CHECK AND TEST RUN

10.1 Check item table after installation

Table 10-1

| Checking item | Description | Yes | No |
|--|---|-----|----|
| Whether installing site is meet for requirements | Units are fixed mounting on level base. | | |
| | Ventilating space for heat exchanger at the air side is correct | | |
| | Maintenance space is correct. | | |
| | Noise and vibration is correct. | | |
| | Sun radiation and rain or snow proof measures are corrects. | | |
| | External physical is correct. | | |
| Whether water system is meeting for requirements | Pipe diameter is correct | | |
| | Thermal insulation is correct | | |
| | Water discharge is correct | | |
| | Water quality control is correct | | |
| | Flexible pipe's connection is correct | | |
| | Pressure control is correct | | |
| Whether electric wiring system is meeting for requirements | Switch capacity is correct | | |
| | Chained control is correct | | |
| | Phase sequence of power supply is meeting for requirement | | |
| | Fuse capacity is correct | | |
| | Voltage and frequency are correct | | |
| | Connecting tightly between wires | | |
| | Operation control device is correct | | |
| | Safety device is correct | | |

10.2 Trial run

- a. Start up the controller and check whether the unit displays a fault code. If a fault occurs, remove the fault first, and start the unit according to the operating method in the "unit control instruction", after determining that there is no fault existing in the unit.
- b. Conduct trial run for 30 minutes. When the influent and effluent temperature becomes stabilized, adjust the water flow to nominal value, to ensure normal operation of the unit.
- c. After the unit is shut down, it should be put into operation 10 min later, to avoid frequent start-up of the unit. In the end, check whether the unit meets the requirements according to the contents in Table 11-1,11-2.



CAUTION

The unit can control start-up and shut-down of the unit, so when the water system is flushed, the operation of the pump should not be controlled by the unit.

Do not start up the unit before draining the water system completely.

The target flow controller must be installed correctly. The wires of the target flow controller must be connected according to electric control schematic diagram, or the faults caused by water breaking while the unit is in operation should be the user's responsibility.

Do not re-start the unit within 10 min after the unit is shut down during trial run.

When the unit is used frequently, do not cut off the power supply after the unit is shut down; otherwise the compressor cannot be heated, thus leading to its damages.

If the unit is not in service for a long time, and the power supply needs to be cut off, the unit should be connected to the power supply 12 hours prior to re-starting of the unit, to pre-heat the compressor, the pump, the plate heat exchanger and the differential pressure value.

11. MAINTENANCE AND UPKEEP

11.1 Failure information and code

In case the unit runs under abnormal condition, failure protection code will display on both control panel and wired controller, and the indicator on the wired controller will flash with 1Hz. The display codes are shown in the following table:

Table11-1 KEM-30 DNS3 and KEM-60 DNS3

| Error No. | Code | reason | note |
|-----------|------|--|--|
| 1 | E0 | Main control parameter memory EPROM failure or inverter module A, B-- Parameter memory EPROM failure | Recovered upon failure recovery |
| | | 1E0--> Main control parameter memory EPROM failure | Recovered upon failure recovery, spot check query |
| | | 2E0-->Inverter module A--Parameter memory EPROM failure | Recovered upon failure recovery |
| | | 3E0-->Inverter module B--Parameter memory EPROM failure | Recovered upon failure recovery |
| 2 | E1 | Phase sequence failure of main control board check | Recovered upon failure recovery |
| 3 | E2 | Main control and wired control communication failure | Recovered upon failure recovery |
| 4 | E3 | Total water outlet temperature sensor failure (main unit valid) | Recovered upon failure recovery |
| 5 | E4 | Unit water outlet temperature sensor failure | Recovered upon failure recovery |
| 6 | E5 | Condenser tube temperature sensor failure | Recovered upon failure recovery |
| 8 | E7 | Ambient temperature sensor failure | Recovered upon failure recovery |
| 10 | E9 | Water flow detection failure (recovered through button) | Protection occurs 3 times in 60 minutes and the failure can be recovered by power disconnection only. |
| 12 | Eb | 1Eb-->Taf1 cooling evaporatorlow-temperature antifreeze protection sensor failure | Recovered upon failure recovery |
| | | 2Eb-->Taf2 cooling evaporatorlow-temperature antifreeze protection sensor failure | Recovered upon failure recovery |
| 13 | EC | Auxiliary unit module reduction (displayed by wired controller) | -- |
| 14 | Ed | 1Ed-->A system discharge temperature sensor failure | Recovered upon failure recovery |
| | | 2Ed-->B system discharge temperature sensor failure | Recovered upon failure recovery |
| 16 | EF | Unit water return temperature sensor failure | Recovered upon failure recovery |
| 17 | EH | System self-check failure alarm | Recovered upon failure recovery |
| 18 | EL | Electronic lock failure (reserved) | Recovered upon failure recovery |
| 19 | EP | Discharge temperature sensor failure alarm | Recovered upon failure recovery |
| 20 | EU | Total cooling outlet temperature sensor (Tz/7) error | Recovered upon failure recovery |
| 21 | P0 | System high-pressure protection or discharge temperature protection | Protection occurs 5 times in 120 minutes and the failure can be recovered by power disconnection only. |
| 22 | P1 | System low pressure protection | Protection occurs 5 times in 120 minutes and the failure can be recovered by power disconnection only. |
| 25 | P4 | System A current protection | Protection occurs 5 times in 120 minutes and the failure can be recovered by power disconnection only. |
| 26 | P5 | System B current protection | Protection occurs 5 times in 120 minutes and the failure can be recovered by power disconnection only. |
| 27 | P6 | 1P6-->IPM module failure, system A protection | -- |
| | | 2P6-->IPM module failure, system B protection | |
| 28 | P7 | High temperature protection of system condenser and total cold water outlet temperature Tz/7 | -- |
| 30 | P9 | Water inlet and outlet temperature difference protection | Recovered upon failure recovery |

| | | | |
|-----|----|--|--|
| 31 | PA | Cooling return water temperature too high | Recovered upon failure recovery |
| 32 | Pb | Winter antifreeze protection | Recovered upon failure recovery |
| 33 | PC | Evaporator pressure low in cooling | Recovered upon failure recovery |
| 35 | PE | Cooling evaporator low-temperature antifreeze protection (recovered through button) | Recovered upon failure recovery |
| 37 | PH | Heating T4 too high temperature protection | Recovered upon failure recovery |
| 38 | PL | Tfin module too high temperature protection | Protection occurs 3 times in 100 minutes and the failure can be recovered by power disconnection only. |
| 40 | PU | 1PU-->DC fan A module protection | Recovered upon failure recovery |
| | | 2PU-->DC fan B module protection | Recovered upon failure recovery |
| 41 | H0 | 1H0: IPM module communication failure | Recovered upon failure recovery |
| | | 2H0: IPM module communication fault | Recovered upon failure recovery |
| 42 | H1 | Over/under-voltage protection | Recovered upon failure recovery |
| 45 | H4 | 1H4: PP protection occurs 3 times in 60 minutes (power failure recovery) | Reserved |
| | | 2H4: PP protection occurs 3 times in 60 minutes (power failure recovery) | Reserved |
| 47 | H6 | 1H6: A system bus voltage failure (PTC) | Recovered upon failure recovery |
| | | 2H6: B system bus voltage failure (PTC) | Recovered upon failure recovery |
| 72 | Fb | Pressure sensor failure | Recovered upon failure recovery |
| 74 | Fd | Air suction temperature sensor failure | Recovered upon failure recovery |
| 76 | FF | 1FF DC fan A failure | Protection occurs 3 times in 20 minutes and the failure can be recovered by power disconnection only. |
| | | 2FF DC fan B failure | Protection occurs 3 times in 20 minutes and the failure can be recovered by power disconnection only. |
| 79 | FP | DIP inconsistency of multiple water pumps | Power failure recovery required |
| 101 | L0 | Inverter module protection | Recovered upon failure recovery |
| 102 | L1 | DC bus low voltage protection | Recovered upon failure recovery |
| 103 | L2 | DC bus high voltage protection | Recovered upon failure recovery |
| 105 | L4 | MCE failure | Recovered upon failure recovery |
| 106 | L5 | zero speed protection | Recovered upon failure recovery |
| 108 | L7 | phase sequence error | Recovered upon failure recovery |
| 109 | L8 | Compressor frequency variation more than 15Hz within one second protection | Recovered upon failure recovery |
| 110 | L9 | Actual compressor frequency differs from target frequency by more than 15Hz protection | Recovered upon failure recovery |
| 146 | dF | Defrosting prompt | Recovered upon failure recovery |

Table 11-2 KEM-90 DNS3

| Error No. | Code | reason | note |
|-----------|------|--|--|
| 1 | E0 | Main control parameter memory EPROM failure | Recovered upon failure recovery |
| 2 | E1 | Phase sequence failure of main control board check | Recovered upon failure recovery |
| 3 | E2 | Main control and wired control communication failure | Recovered upon failure recovery |
| 4 | E3 | Total water outlet temperature sensor failure (main unit valid) | Recovered upon failure recovery |
| 5 | E4 | Unit water outlet temperature sensor failure | Recovered upon failure recovery |
| 6 | E5 | 1E5 condenser tube temperature sensor T3A failure | Recovered upon failure recovery |
| | | 2E5 condenser tube temperature sensor T3B failure | Recovered upon failure recovery |
| 8 | E7 | Ambient temperature sensor failure | Recovered upon failure recovery |
| 9 | E8 | Power supply phase sequence protector output failure (reserved) | Recovered upon failure recovery |
| 10 | E9 | Water flow detection failure (recovered through button) | Protection occurs 3 times in 60 minutes and the failure can be recovered by power disconnection only. |
| 12 | Eb | 1Eb-->Taf1 cooling evaporator low-temperature antifreeze protection sensor failure | Recovered upon failure recovery |
| | | 2Eb-->Taf2 cooling evaporator low-temperature antifreeze protection sensor failure | Recovered upon failure recovery |
| 13 | EC | auxiliary unit module reduction | Recovered upon failure recovery |
| 14 | Ed | 1Ed-->A system discharge temperature sensor failure | Recovered upon failure recovery |
| | | 2Ed-->B system discharge temperature sensor failure | Recovered upon failure recovery |
| 15 | EE | 1EE EVI plate heat exchanger refrigerant temperature T6A sensor failure | Recovered upon failure recovery |
| | | 2EE EVI plate heat exchanger refrigerant temperature T6B sensor failure | |
| 16 | EF | Unit water return temperature sensor failure | Recovered upon failure recovery |
| 17 | EH | System self-check failure alarm | Recovered upon failure recovery |
| 19 | EP | Discharge temperature sensor failure alarm | Recovered upon failure recovery |
| 20 | EU | Tz/7 Coil final outlet temperature sensor error | Recovered upon failure recovery |
| 21 | P0 | System high-pressure protection or discharge temperature protection | Protection occurs 3 times in 60 minutes and the failure can be recovered by power disconnection only. |
| 22 | P1 | System low pressure protection | Protection occurs 3 times in 60 minutes and the failure can be recovered by power disconnection only. |
| 23 | P2 | Tz/7 Coil final outlet temperature too high | Recovered upon failure recovery |
| 25 | P4 | System A current protection | Protection occurs 3 times in 60 minutes and the failure can be recovered by power disconnection only. |
| 26 | P5 | System B current protection | Protection occurs 3 times in 60 minutes and the failure can be recovered by power disconnection only. |
| 27 | P6 | Module failure | Protection occurs 3 times in 60 minutes and the failure can be recovered by power disconnection only. |
| 28 | P7 | High temperature protection of system condenser | Protection occurs 3 times in 60 minutes and the failure can be recovered by power disconnection |
| 30 | P9 | Water inlet and outlet temperature difference protection | Protection occurs 3 times in 60 minutes and the failure can be recovered by power disconnection |
| 32 | Pb | Winter antifreeze protection | Recovered upon failure recovery |
| 33 | PC | Evaporator pressure low in cooling | Recovered upon failure recovery |
| 35 | PE | Cooling evaporator low temperature antifreeze protection | Recovered upon failure recovery |
| 37 | PH | Heating T4 too high temperature protection | Valid for heating |
| 38 | PL | Tfin module too high temperature protection | Protection occurs 3 times in 100 minutes and the failure can be recovered by power disconnection only. |
| 40 | PU | 1PU-->DC fan A module protection | Recovered upon failure recovery |
| | | 2PU-->DC fan B module protection | Recovered upon failure recovery |
| | | 3PU-->DC fan C module protection | Recovered upon failure recovery |
| 46 | H5 | pressure too high or low | Recovered by power disconnection |
| 50 | xH9 | Drive model not matched | x indicates the compressor: 1 indicates compressor A, and 2 indicates compressor B. |

| | | | |
|-----|----|--|--|
| 55 | HE | 1HE Not insert electronic expansion valve A error | Recovered upon failure recovery |
| | | 2HE Not insert electronic expansion valve B error | Recovered upon failure recovery |
| | | 3HE Not insert electronic expansion valve C error | Recovered upon failure recovery |
| 61 | F0 | 1F0: IPM module communication failure | Recovered upon failure recovery |
| | | 2F0: IPM module communication failure | Recovered upon failure recovery |
| 63 | F2 | Superheat insufficient | Protection occurs 3 times in 240 minutes and the failure can be recovered by power disconnection only. |
| 65 | F4 | 1F4: L0 or L1 protection occurs 3 times in 60 minutes (power failure recovery) | Recovered upon failure recovery |
| | | 2F4: L0 or L1 protection occurs 3 times in 60 minutes (power failure recovery) | Recovered upon failure recovery |
| 67 | F6 | 1F6: System A DC bus voltage fault (PTC) | Recovered upon failure recovery |
| | | 2F6: System B DC bus voltage fault (PTC) | Recovered upon failure recovery |
| 70 | F9 | 1F9: TF1 radiator temperature sensor failure 1 F9 | Recovered upon failure recovery |
| | | 2F9: TF2 radiator temperature sensor failure 2 F9 | Recovered upon failure recovery |
| 72 | Fb | Pressure sensor error | Recovered upon failure recovery |
| 74 | Fd | Suction temperature sensor failure | Recovered upon failure recovery |
| 76 | FF | 1FF DC fan A failure | Failure can only be recovered by disconnecting the power |
| | | 2FF DC fan B failure | Failure can only be recovered by disconnecting the power |
| | | 3FF DC fan C failure | Failure can only be recovered by disconnecting the power |
| 79 | FP | DIP inconsistency of multiple water pumps | Power failure recovery required |
| 88 | C7 | If PL occurs 3 times, the system reports the C7 failure | Power failure recovery required |
| 101 | L0 | Inverter module protection | Recovered upon failure recovery |
| 102 | L1 | DC bus low voltage protection | Recovered upon failure recovery |
| 103 | L2 | DC bus high voltage protection | Recovered upon failure recovery |
| 105 | L4 | MCE failure | Recovered upon failure recovery |
| 106 | L5 | zero speed protection | Recovered upon failure recovery |
| 108 | L7 | Phase sequence error | Recovered upon failure recovery |
| 109 | L8 | Compressor frequency change over 15Hz | Recovered upon failure recovery |
| 110 | L9 | Compressor frequency phase difference 15Hz | Recovered upon failure recovery |
| 146 | dF | Defrosting prompt | Recovered upon failure recovery |

11.2 Digital display of main board

The data display area is divided into Up area and Down area, with two groups of two-digit half 7-segment digital display, respectively.

a. Temperature display

Temperature display is used for displaying the total outlet water temperature of unit system, outlet water temperature, condenser pipe temperature T3A of system A, condenser pipe temperature T3B of system B, outdoor environmental temperature T4, anti-freezing temperature T6 and setting temperature Ts, with allowable data display scope -15°C-70°C. If the temperature is higher than 70°C, it is displayed as 70°C. If there is no effective date, it displays “— —” and indication point °C is on.

b. Current display

Current display is used for displaying Modular unit system A compressor current IA or system B compressor current IB, with allowable display scope 0A~99A. If it is higher than 99A, it is displayed as 99A. If there is no effective date, it displays “— —” and indication point A is on.

c. Failure display

It is used for displaying the total failure warning date of unit or that of Modular unit, with failure display scope E0~EF, E indicating failure, 0~F indicating failure code. “E-” is displayed when there is no failure and indication point # is on at the same time.

d. Protection display

It is used for displaying the total system protection data of unit or the system protection data of Modular unit, with protection display scope P0~PF, P indicating system protection, 0~F indicating protection code. “P-” is displayed when there is no failure.

e. Unit number display

It is used for displaying the address number of the currently selected Modular unit, with display scope 0~15 and indication point is on at the same time.

f. Display of online unit number and startup unitnumber

They are used for displaying the total online Modular units of the whole unit system and the number of the Modular unit under running state, respectively, with display scope 0~16.

Any time when the spot check page is entered to display or change Modular unit, it is needed to wait for the up-to-date data of the Modular unit received and selected by wired controller.

Before receiving the data, the wired controller only displays “——” on the data display Down area, and the Up area displays the address number of the Modular unit. No page can be turned, which continues until the wired controller receives the communication data of this Modular unit.

11.3 Care and maintenance

Maintenance period

It's recommended that before cooling in summer and heating in winter every year, consult local air conditioner customer service center to check and maintain the unit, to prevent air conditioner errors which bring inconvenience to your life and work.

Maintenance of main parts

- Close attention should be paid to the discharge and suction pressure during the running process. Find out reasons and eliminate the failure if abnormality is found.
- Control and protect the equipment. See to it that no random adjustment be made on the set points on site.
- Regularly check whether the electric connection is loose, and whether there is bad contact at the contact point caused by oxidation and debris etc., and take timely measures if necessary. Frequently check the work voltage, current and phase balance.
- Check the reliability of the electric elements in time. Ineffective and unreliable elements should be replaced in time.

11.4 Removing scale

After long-time operation, calcium oxide or other minerals will be settled in the heat transfer surface of the water-side heat exchanger. These substances will affect the heat transfer performance when there is too much scale in the heat transfer surface and sequentially cause that electricity consumption increases and the discharge pressure is too high (or suction pressure too low). Organic acids such as formic acid, citric acid and acetic acid may be used to clean the scale. But in no way should cleaning agent containing fluoroacetic acid or fluoride should be used as the water-side heat exchange is made from stainless steel and is easy to be eroded to cause refrigerant leakage. Pay attention to the following aspects during the cleaning and scale-removing process:

- Water-side heat exchanger should be done by professionals. Please contact the local air-conditioner customer service center.
- Clean the pipe and heat exchanger with clean water after cleaning agent is used. Conduct water treatment to prevent water system from being eroded or re-absorption of scale.
- In case of using cleaning agent, adjust the density of the agent, cleaning time and temperature according to the scale settlement condition.
- After pickling is completed, neutralization treatment needs to be done on the waste liquid. Contact relevant company for treating the treated waste liquid.
- Protection equipments (such as goggles, gloves, mask and shoes) must be used during the cleaning process to avoid breathing in or contacting the agent as the cleaning agent and neutralization agent is corrosive to eyes, skins and nasal mucosa.

11.5 Winter shutdown

For shutdown in winter, the surface of the unit outside and inside should be cleaned and dried. Cover the unit to prevent dust. Open discharge water valve to discharge the stored water in the clean water system to prevent freezing accident (it is preferable to inject antifreezer in the pipe).

11.6 Replacing parts

Parts to be replaced should be the ones provided by our company. Never replace any part with different part.

11.7 First startup after shutdown

The following preparations should be made for re-startup of unit after long-time shutdown:

- Thoroughly check and clean the unit.
- Clean water pipe system.
- Check pump, control valve and other equipments of water pipe system.
- Fix connections of all wires.
- It is a must to electrify the machine 12 hours before startup.

11.18 Refrigeration system

Determine whether refrigerant is needed by checking the value of suction and discharge pressure and check whether there is a leakage. Air tight test must be made if there is a leakage or parts of refrigerating system is to be replaced. Take different measures in the following two different conditions from refrigerant injection.

Total leakage of refrigerant. In case of such situation, leakage detection must be made on the pressurized nitrogen used for the system. If repair welding is needed, welding cannot be made until all the gas in the system is discharged. Before injecting refrigerant, the whole refrigeration system must be completely dry and of vacuum pumping.

- Connect vacuum pumping pipe at the fluoride nozzle at low-pressure side.
- Remove air from the system pipe with vacuum pump. The vacuum pumping lasts for above 3 hours. Confirm that the indication pressure in dial gauge is within the specified scope.

- c. When the degree of vacuum is reached, inject refrigerant into the refrigeration system with refrigerant bottle. Appropriate amount of refrigerant for injection has been indicated on the nameplate and the table of main technical parameters. Refrigerant must be injected from the low pressure side of system.
- d. The injection amount of refrigerant will be affected by the ambient temperature. If the required amount has not been reached but no more injection can be done, make the chilled water circulate and start up the unit for injection. Make the low pressure switch temporarily short circuit if necessary.

Refrigerant supplement. Connect refrigerant injection bottle on the fluoride nozzle at low-pressure side and connect pressure gauge at low pressure side.

- a. Make chilled water circulate and start up unit, and make the low pressure control switch short circuit if necessary.
- b. Slowly inject refrigerant into the system and check suction and discharge pressure.



CAUTION

Connection must be renewed after injection is completed.

Never inject oxygen, acetylene or other flammable or poisonous gas to the refrigeration system at leakage detection and air tight test. Only pressurized nitrogen or refrigerant can be used.

11.9 Disassembling compressor

Follow the following procedures if compressor needs to be disassembled:

- a. Cut off the power supply of unit.
- b. Remove power source connection wire of compressor.
- c. Remove suction and discharge pipes of compressor.
- d. Remove fastening screw of compressor.
- e. Move the compressor.

11.10 Auxiliary electric heater

When the ambient temperature is lower than 2°C, the heating efficiency decreases with the decline of the outdoor temperature. In order to make the air-cooled heat pump stably run in a relatively cold region and supplement some heat lost due to de-frosting. When the lowest ambient temperature in the user's region in winter is within 0°C~10°C, the user may consider to use auxiliary electric heater.

Please refer to relevant professionals for the power of auxiliary electric heater.

11.11 Antifreezing

In case of freezing at the water-side heat exchanger interval channel, severe damage may be caused, i.e. heat exchange may be broken and appears leakage. This damage of frost crack is not within the warranty scope, so attention must be paid to antifreezing.

- a. If the unit that is shutdown for standby is placed in an environment where the outdoor temperature is lower than 0°C, the water in the water system should be drained.
- b. Water pipe may be frozen when the chilled water target flow controller and anti-freezing temperature sensor become ineffective at running, therefore, the target flow controller must be connected in accordance with the connection diagram.
- c. Frost crack may happen to water-side heat exchanger at maintenance when refrigerant is injected to the unit or is discharged for repair. Pipe freezing is likely to happen any time when the pressure of refrigerant is below 0.4Mpa. Therefore, the water in the heat exchanger must be kept flowing or be thoroughly discharged.

11.12 Replacement of safety valve

Replace the safety valve as follows:

- a. Reclaim the refrigerant completely in the system. Doing so requires professional staff and equipment;
- b. Note to protect the tank coating. Avoid damage to coating from external force or high temperature when removing and installing the safety valve;
- c. Heat the sealant to screw off the safety valve. Note to protect the area where the screwing tool meets the tank body and avoid damages to the tank coating;
- d. If tank coating is damaged, repaint the damaged area.




Fig. 11-1 Replacement of safety valve



WARNING

Safety valve warranty period is 24 months. Under the specified conditions, if flexible sealing parts is used, the safety valve life expectancy is 24 to 36 months, if metal or PIFE sealing components is used, the average life expectancy is 36 to 48 months. Visual inspection is needed after that period, maintenance people should check the appearance of the valve body and the operating environment. If the valve body is not obvious corrosion, cracks, dirt, damage, then the valve can be used continually. Otherwise, please contact your supplier for spare part.

RECORD TABLE OF TEST RUN AND MAINTENANCE

Table 11-5

| | |
|----------------------------|---------------------------|
| Model: | Code labeled on the unit: |
| Customer name and address: | Date: |

1. Check temperature of chilled water or hot water

Inlet () Outlet ()

2. Check air temperature of air-side heat exchanger:

Inlet () Outlet ()

3. Check refrigerant suction temperature and superheating temperature:

Refrigerant suction temperature: () () () () ()

Superheating temperature: () () () () ()

4. Check pressure:

Discharge pressure: () () () () ()

Suction pressure: () () () () ()

5. Check running current: () () () () ()

6. Whether unit has been through refrigerant leakage test? ()

7. Whether there is noise on all the panels of unit? ()

8. Check whether the main power source connection is correct. ()

RECORD TABLE OF ROUTINE RUNNING

Table 11-6

| | | | | | | | | | | | |
|---|-------------------|-----|--|--|--|--|--|--|--|--|--|
| Model: | | | | | | | | | | | |
| Date: | | | | | | | | | | | |
| Weather: | | | | | | | | | | | |
| Operation time: Startup () Shutdown () | | | | | | | | | | | |
| Outdoor temperature | Dry bulb | °C | | | | | | | | | |
| | Wet bulb | °C | | | | | | | | | |
| Indoor temperature | | °C | | | | | | | | | |
| Compressor | High pressure | MPa | | | | | | | | | |
| | Low pressure | MPa | | | | | | | | | |
| | Voltage | V | | | | | | | | | |
| | Current | A | | | | | | | | | |
| Air temperature of air-side heat exchanger | Inlet (dry bulb) | °C | | | | | | | | | |
| | Outlet (dry bulb) | °C | | | | | | | | | |
| Temperature of chilled water or hot water | Inlet | °C | | | | | | | | | |
| | Outlet | °C | | | | | | | | | |
| Current of water pump | | A | | | | | | | | | |
| Note: | | | | | | | | | | | |

12. APPLICABLE MODELS AND MAIN PARAMETERS

Table 12-1

| Model | | KEM-30 DNS3 | KEM-60 DNS3 | KEM-90 DNS3 |
|---------------------------------------|---------------------------------|----------------------|----------------|----------------|
| Cooling capacity | kW | 27 | 55 | 82 |
| Heating capacity | kW | 31 | 61 | 90 |
| Standard cooling input | kW | 10.8 | 22 | 36.8 |
| Cooling rated current | A | 16.7 | 33.9 | 60 |
| Standard heating input | kW | 10.5 | 20.3 | 32.8 |
| Heating rated current | A | 16.2 | 31.3 | 53.5 |
| Power supply | | 380-415V 3N ~ 50 | | |
| Refrigerant | Type | R410A | | |
| | Charging volume kg | 10.5 | 17.0 | 27.0 |
| Water pipe system | Water Folw volume (m³/h) | 5.0 | 9.8 | 15 |
| | Hydraulic resistance lose kPa | 80 | 50 | 75 |
| | Water side heat exchanger | Plate heat exchanger | | |
| | Max. pressure MPa | 1.0 | | |
| | Min. pressure MPa | 0.05 | | |
| | Inlet and outlet pip e diameter | DN40 | DN50 | |
| Air side heat exchanger | Type | Fin coil model | | |
| | Air flow volume (m³/h) | 12500 | 24000 | 38000 |
| Outline dimension N.W. of the unit | L (mm) | 1870 | 2220 | 3220 |
| | W (mm) | 1000 | 1055 | 1095 |
| | H (mm) | 1175 | 1325 | 1513 |
| Net Weight | kg | 300 | 480 | 710 |
| Operation Weight | kg | 310 | 490 | 739 |
| Packing dimension | L×W×H (mm) | 1910×1035×1225 | 2250×1090×1370 | 3275×1130×1540 |

13. INFORMATION REQUIREMENTS

Table 13-1

| Information requirements for comfort chillers | | | | | | | | |
|--|----------------------|--------------------------------------|-----------------------------------|--|--|------------------|-------|------|
| Model(s) | | KEM-30 DNS3 | | | | | | |
| Outdoor side heat exchanger | | Air to water | | | | | | |
| Indoor side heat exchanger | | Water to air | | | | | | |
| Type | | Compressor driven vapour compression | | | | | | |
| Driver of compressor: | | Electric motor | | | | | | |
| | | | | | | | | |
| Item | Symbol | Value | Unit | | Item | Symbol | Value | Unit |
| Rated cooling capacity | Prate _{d,c} | 27.6 | kW | | Seasonal space cooling energy efficiency | η _{s,c} | 160 | % |
| Declared cooling capacity for part load at given outdoor temperature T _j | | | | | Declared energy efficiency ratio for part load at given outdoor temperature T _j | | | |
| T _j = + 35°C | P _{dc} | 27.6 | kW | | T _j = + 35°C | EER _d | 2.52 | -- |
| T _j = + 30°C | P _{dc} | 22.0 | kW | | T _j = + 30°C | EER _d | 3.64 | -- |
| T _j = + 25°C | P _{dc} | 13.2 | kW | | T _j = + 25°C | EER _d | 5.05 | -- |
| T _j = + 20°C | P _{dc} | 8.1 | kW | | T _j = + 20°C | EER _d | 6.40 | -- |
| Degradation co-efficient for chillers (*) | C _{dc} | 0.9 | -- | | | | | |
| Power consumption in modes other than 'active mode' | | | | | | | | |
| Off mode | P _{OFF} | 0.08 | kW | | Crankcase heater mode | P _{CK} | 0.08 | kW |
| Thermostat-off mode | P _{TO} | 0.21 | kW | | Standby mode | P _{SB} | 0.08 | kW |
| Other items | | | | | | | | |
| Capacity control | variable | | | | For air-to-water comfort chillers: air flow rate, outdoor measured | — | 12500 | m³/h |
| Sound power level, indoors / outdoors | L _{WA} | -78 | dB | | For water / brine-to-water chillers: Rated brine or water flow rate, outdoor side heat exchanger | — | - | m³/h |
| Emissions of nitrogen oxides (if applicable) | NO _x (**) | -- | mg/kWh input GCV | | | | | |
| GWP of the refrigerant | — | 2088 | kg CO ₂ eq (100 years) | | | | | |
| Standard rating conditions used: | | Low temperature application | | | | | | |
| (*) If C _{dc} is not determined by measurement then the default degradation coefficient of chillers shall be 0,9. | | | | | | | | |
| (**) From 26 September 2018. | | | | | | | | |

Table 13-2

| Information requirements for comfort chillers | | | | | | | | |
|--|----------------------|--------------------------------------|-----------------------------------|--|--|------------------|-------|------|
| Model(s): | | KEM-60 DNS3 | | | | | | |
| Outdoor side heat exchanger of chiller: | | Air to water | | | | | | |
| Indoor side heat exchanger chiller: | | Water to air | | | | | | |
| Type: | | Compressor driven vapour compression | | | | | | |
| Driver of compressor: | | Electric motor | | | | | | |
| | | | | | | | | |
| Item | Symbol | Value | Unit | | Item | Symbol | Value | Unit |
| Rated cooling capacity | Prate _{d,c} | 55.5 | kW | | Seasonal space cooling energy efficiency | η _{s,c} | 154 | % |
| Declared cooling capacity for part load at given outdoor temperature T _j | | | | | Declared energy efficiency ratio for part load at given outdoor temperature T _j | | | |
| T _j = + 35°C | P _{dc} | 55.5 | kW | | T _j = + 35°C | EER _d | 2.44 | -- |
| T _j = + 30°C | P _{dc} | 41.8 | kW | | T _j = + 30°C | EER _d | | -- |
| T _j = + 25°C | P _{dc} | 25.9 | kW | | T _j = + 25°C | EER _d | 4.82 | -- |
| T _j = + 20°C | P _{dc} | 11.9 | kW | | T _j = + 20°C | EER _d | 4.82 | -- |
| Degradation co-efficient for chillers (*) | C _{dc} | 0.9 | -- | | | | | |
| Power consumption in modes other than 'active mode' | | | | | | | | |
| Off mode | P _{OFF} | 0.07 | kW | | Crankcase heater mode | P _{CK} | 0.07 | kW |
| Thermostat-off mode | P _{TO} | 0.40 | kW | | Standby mode | P _{SB} | 0.07 | kW |
| Other items | | | | | | | | |
| Capacity control | variable | | | | For air-to-water comfort chillers: air flow rate, outdoor measured | — | 24000 | m³/h |
| Sound power level, indoors / outdoors | LWA | -87 | dB | | For water / brine-to-water rate, outdoor side heat exchanger | — | -- | m³/h |
| Emissions of nitrogen oxides (if applicable) | NO _x (**) | -- | mg/kWh input GCV | | | | | |
| GWP of the refrigerant | — | 2088 | kg CO ₂ eq (100 years) | | | | | |
| Standard rating conditions used: | | Low temperature application | | | | | | |
| (*) If C _{dc} is not determined by measurement then the default degradation coefficient of chillers shall be 0,9. | | | | | | | | |
| (**) From 26 September 2018. | | | | | | | | |

Table 13-3

| Information requirements for comfort chillers | | | | | | | | |
|--|-----------|--------------------------------------|-----------------------|--|--|--------|-------|------|
| Model(s): | | KEM-90 DNS3 | | | | | | |
| Outdoor side heat exchanger of chiller: | | Air to water | | | | | | |
| Indoor side heat exchanger chiller: | | Water to air | | | | | | |
| Type: | | Compressor driven vapour compression | | | | | | |
| Driver of compressor: | | Electric motor | | | | | | |
| | | | | | | | | |
| Item | Symbol | Value | Unit | | Item | Symbol | Value | Unit |
| Rated cooling capacity | Prate,d,c | 82.0 | kW | | Seasonal space cooling energy efficiency | ηs,c | 160 | % |
| Declared cooling capacity for part load at given outdoor temperature Tj | | | | | Declared energy efficiency ratio for part load at given outdoor temperature Tj | | | |
| Tj = + 35°C | Pdc | 82.0 | kW | | Tj = + 35°C | EERd | 2.27 | -- |
| Tj = + 30°C | Pdc | 62.9 | kW | | Tj = + 30°C | EERd | 3.54 | -- |
| Tj = + 25°C | Pdc | 41.4 | kW | | Tj = + 25°C | EERd | 4.40 | -- |
| Tj = + 20°C | Pdc | 30.9 | kW | | Tj = + 20°C | EERd | 6.10 | -- |
| Degradation co-efficient for chillers (*) | Cdc | 0.9 | -- | | | | | |
| Power consumption in modes other than 'active mode' | | | | | | | | |
| Off mode | Poff | 0.04 | kW | | Crankcase heater mode | Pck | 0.04 | kW |
| Thermostat-off mode | Pto | 0.11 | kW | | Standby mode | Psb | 0.04 | kW |
| Other items | | | | | | | | |
| Capacity control | variable | | | | For air-to-water comfort chillers: air flow rate, outdoor measured | — | 38000 | m³/h |
| Sound power level, indoors / outdoors | LWA | -/89 | dB | | For water / brine-to-water chillers: Rated brine or water flow rate, outdoor side heat exchanger | — | -- | m³/h |
| Emissions of nitrogen oxides (if applicable) | NOx(**) | -- | mg/kWh input GCV | | | | | |
| GWP of the refrigerant | — | 2088 | kg CO2 eq (100 years) | | | | | |
| Standard rating conditions used: | | Low temperature application | | | | | | |
| (*) If Cdc is not determined by measurement then the default degradation coefficient of chillers shall be 0,9. (**) From 26 September 2018. | | | | | | | | |

Table 13-4

| Information requirements for heat pump space heaters and heat pump combination heaters | | | | | | | |
|--|--|-------------|-------|---|--|----------|------|
| Model(s): | | KEM-30 DNS3 | | | | | |
| Air-to-water heat pump: | | | | | | [yes] | |
| Water-to-water heat pump: | | | | | | [yes/no] | |
| Brine-to-water heat pump: | | | | | | [yes/no] | |
| Low-temperature heat pump: | | | | | | [yes/no] | |
| For low-temperature heat pumps, parameters shall be declared for low-temperature application. Otherwise, parameters shall be declared for medium-temperature application. | | | | | | | |
| Parameters shall be declared for average climate conditions. | | | | | | | |
| Item | Symbol | Value | Unit | Item | Symbol | Value | Unit |
| Rated heat output ⁽³⁾ at T _{designh} = -10 (-11)°C | Prated = P _{designh} | 21 | kW | Seasonal space heating energy efficiency | η _s | 157 | % |
| Seasonal coefficient of performance | SCOP | 4.01 | – | Active mode coef. of performance | SCOP _{on} | x.xx | – |
| | | | | Net seasonal coef. of performance | SCOP _{net} | | – |
| | | | | | | | |
| T _j = – 7°C | P _{dh} | 19.2 | kW | T _j = – 7°C | COP _d | 2.59 | – |
| T _j = + 2°C | P _{dh} | 10.9 | kW | T _j = + 2°C | COP _d | 3.84 | – |
| T _j = + 7°C | P _{dh} | 7.2 | kW | T _j = + 7°C | COP _d | 5.21 | – |
| T _j = + 12°C | P _{dh} | 8.7 | kW | T _j = + 12°C | COP _d | 7.10 | – |
| T _j = bivalent temperature | P _{dh} | 22.2 | kW | T _j = bivalent temperature | COP _d | 2.34 | – |
| T _j = operation limit temperature | P _{dh} | 22.2 | kW | T _j = operation limit temperature | COP _d | 2.34 | – |
| For air-to-water heat pumps: T _j = – 15°C (if TOL < – 20°C) | P _{dh} | x,x | kW | For air-to-water heat pumps: T _j = – 15°C (if TOL < – 20°C) | COP _d | x,xx | – |
| Bivalent temperature (maximum +2°C) | T _{biv} | -10 | °C | For air-to-water HP: Operation limit temperature (maximum -7°C) | TOL | -10 | °C |
| Cycling interval capacity for heating at T _j = -7°C | P _{cyh} | x,x | kW | Heating water operating limit temperature | WTOL | x | °C |
| Degradation coefficient ⁽⁴⁾ at T _j = -7°C | C _{dh} | x,xx | — | Cycling interval efficiency at T _j = +7°C | COP _{cyh} | x,xx | – |
| Cycling interval capacity for heating at T _j = +2°C | P _{cyh} | x,x | kW | | | | |
| Degradation coefficient ⁽⁴⁾ at T _j = +2°C | C _{dh} | x,xx | — | Cycling interval efficiency at T _j = +12°C | COP _{cyh} | x,xx | – |
| Cycling interval capacity for heating at T _j = +7°C | P _{cyh} | x,x | kW | Cycling interval efficiency at T _j = +7°C | COP _{cyh} | x,xx | – |
| Degradation coefficient ⁽⁴⁾ at T _j = +7°C | C _{dh} | x,xx | — | Cycling interval efficiency at T _j = +12°C | COP _{cyh} | x,xx | – |
| Cycling interval capacity for heating at T _j = +12°C | P _{cyh} | x,x | kW | | | | |
| Degradation coefficient ⁽⁴⁾ at T _j = +12°C | C _{dh} | x,xx | — | | | | |
| Power consumption in modes other than active mode | | | | Supplementary heater (to be declared even if not provided in the unit) | | | |
| Off mode | P _{OFF} | 0.08 | kW | Rated heat output (3) | P _{sup} = sup(T _j) | x,x | kW |
| Thermostat-off mode | P _{TO} | 0.21 | kW | Type of energy input | | | |
| Standby mode | P _{SB} | 0.08 | kW | | | | |
| Crankcase heater mode | P _{CK} | 0.08 | kW | | | | |
| Other items | | | | Outdoor heat exchanger | | | |
| Capacity control | fixed/variable | variable | | For air-to-water HP: Rated air flow rate | Q _{airsource} | 12500 | m³/h |
| Sound power level, indoors | L _{WA} | x | dB(A) | For water-to-water: Rated water flow rate | Q _{watersource} | x | m³/h |
| Sound power level, outdoors | L _{WA} | 78 | dB(A) | For brine-to-water: Rated brine flow rate | Q _{brinesource} | x | m³/h |
| Contact details | Name and address of the manufacturer or its authorised representative. | | | | | | |
| (1) For heat pump space heaters and heat pump combination heaters, the rated heat output Prated is equal to the design load for heating Pdesignh, and the rated heat output of a supplementary heater Psup is equal to the supplementary capacity for heating sup(Tj). | | | | | | | |
| (2) If Cdh is not determined by measurement then the default degradation coefficient is Cdh = 0.9. | | | | | | | |

Table 13-5

| Information requirements for heat pump space heaters and heat pump combination heaters | | | | | | | |
|--|--|-------------|-------|--|-------------------------------|-------|-------------------|
| Model(s): | | KEM-60 DNS3 | | | | | |
| Air-to-water heat pump: | | | | | | | [yes] |
| Water-to-water heat pump: | | | | | | | [yes/no] |
| Brine-to-water heat pump: | | | | | | | [yes/no] |
| Low-temperature heat pump: | | | | | | | [yes/no] |
| Equipped with a supplementary heater: | | | | | | | [yes/no] |
| Heat pump combination heater: | | | | | | | [yes/no] |
| For low-temperature heat pumps, parameters shall be declared for low-temperature application. | | | | | | | |
| Otherwise, parameters shall be declared for medium-temperature application. Parameters shall be declared for average climate conditions. | | | | | | | |
| Item | Symbol | Value | Unit | Item | Symbol | Value | Unit |
| Rated heat output ⁽³⁾ at Tdesignh = -10 (-11)°C | Prated = Pdesignh | 31 | kW | Seasonal space heating energy efficiency | ηs | 151 | % |
| Seasonal coefficient of performance | SCOP | 3.85 | — | Active mode coef. of performance | SCOPon | X.XX | — |
| | | | | Net seasonal coef. of performance | SCOPnet | X.XX | — |
| | | | | | | | |
| Tj = − 7°C | Pdh | 27.3 | kW | Tj = − 7°C | COPd | 2.70 | — |
| Tj = + 2°C | Pdh | 17.1 | kW | Tj = + 2°C | COPd | 3.69 | — |
| Tj = + 7°C | Pdh | 15.4 | kW | Tj = + 7°C | COPd | 5.04 | — |
| Tj = + 12°C | Pdh | 12.5 | kW | Tj = + 12°C | COPd | 6.43 | — |
| Tj = bivalent temperature | Pdh | 27.3 | kW | Tj = bivalent temperature | COPd | 2.70 | — |
| Tj = operation limit temperature | Pdh | 31.5 | kW | Tj = operation limit temperature | COPd | 2.50 | — |
| For air-to-water heat pumps: Tj = − 15°C (if TOL < − 20°C) | Pdh | x,x | kW | For air-to-water heat pumps: Tj = − 15°C (if TOL < − 20°C) | COPd | x,xx | — |
| Bivalent temperature (maximum +2°C) | Tbiv | -7 | °C | For air-to-water HP: Operation limit tem- perature (maximum -7°C) | TOL | -10 | °C |
| Cycling interval capacity for heating at Tj = -7°C | Pcyh | x,x | kW | Heating water operating limit temperature | WTOL | x | °C |
| Degradation coefficient ⁽⁴⁾ at Tj = -7°C | Cdh | x,xx | — | Cycling interval efficiency at Tj= +7°C | COPcyh | x,xx | — |
| Cycling interval capacity for heating at Tj = +2°C | Pcyh | x,x | kW | Cycling interval efficiency at Tj= +12°C | COPcyh | x,xx | — |
| Degradation coefficient ⁽⁴⁾ at Tj = +2°C | Cdh | x,xx | — | Cycling interval efficiency at Tj= +7°C | COPcyh | x,xx | — |
| Cycling interval capacity for heating at Tj = +7°C | Pcyh | x,x | kW | Cycling interval efficiency at Tj= +12°C | COPcyh | x,xx | — |
| Degradation coefficient ⁽⁴⁾ at Tj = +7°C | Cdh | x,xx | — | | | | |
| Cycling interval capacity for heating at Tj = +12°C | Pcyh | x,x | kW | | | | |
| Degradation coefficient ⁽⁴⁾ at Tj = +12°C | Cdh | x,xx | — | | | | |
| Power consumption in modes other than active mode | | | | Supplementary heater (to be declared even if not provided in the unit) | | | |
| Off mode | P _{OFF} | 0.08 | kW | Rated heat output (3) | P _{sup} = sup(Tj) | x,x | kW |
| Thermostat-off mode | P _{TO} | 0.40 | kW | Type of energy input | | | |
| Standby mode | P _{SB} | 0.08 | kW | | | | |
| Crankcase heater mode | P _{CK} | 0.08 | kW | | | | |
| Other items | | | | Outdoor heat exchanger | | | |
| Capacity control | fixed/variable | variable | | For air-to-water HP: Rated air flow rate | Q _{airsource} | 24000 | m ³ /h |
| Sound power level, indoors | L _{WA} | x | dB(A) | For water-to-water: Rated water flow rate | Q _{watersource} | x | m ³ /h |
| Sound power level, outdoors | L _{WA} | 87 | dB(A) | For brine-to-water: Rated brine flow rate | Q _{brinesource} | x | m ³ /h |
| Contact details | Name and address of the manufacturer or its authorised representative. | | | | | | |
| (1) For heat pump space heaters and heat pump combination heaters, the rated heat output Prated is equal to the design load for heating Pdesignh, and the rated heat output of a supplementary heater Psup is equal to the supplementary capacity for heating sup(Tj). | | | | | | | |
| (2) If Cdh is not determined by measurement then the default degradation coefficient is Cdh = 0,9. | | | | | | | |

Table 13-6

| Information requirements for heat pump space heaters and heat pump combination heaters | | | | | | | |
|--|--|-------------|-------|---|---|-------|-------------------|
| Model(s): | | KEM-90 DNS3 | | | | | |
| Air-to-water heat pump: | | | | | | | [yes] |
| Water-to-water heat pump: | | | | | | | [yes/no] |
| Brine-to-water heat pump: | | | | | | | [yes/no] |
| Low-temperature heat pump: | | | | | | | [yes/no] |
| Equipped with a supplementary heater: | | | | | | | [yes/no] |
| Heat pump combination heater: | | | | | | | [yes/no] |
| For low-temperature heat pumps, parameters shall be declared for low-temperature application. | | | | | | | |
| Otherwise, parameters shall be declared for medium-temperature application. Parameters shall be declared for average climate conditions. | | | | | | | |
| Item | Symbol | Value | Unit | Item | Symbol | Value | Unit |
| Rated heat output ⁽³⁾ at T _{designh} = -10 (-11)°C | Prated = P _{designh} | 66.3 | kW | Seasonal space heating energy efficiency | η _s | 157 | % |
| Seasonal coefficient of performance | SCOP | 3.99 | — | Active mode coef. of performance | SCOP _{on} | X.XX | — |
| | | | | Net seasonal coef. of performance | SCOP _{net} | X.XX | — |
| | | | | | | | |
| T _j = - 7°C | P _{dh} | 58.7 | kW | T _j = - 7°C | COP _d | 2.49 | — |
| T _j = + 2°C | P _{dh} | 35.9 | kW | T _j = + 2°C | COP _d | 3.78 | — |
| T _j = + 7°C | P _{dh} | 28.2 | kW | T _j = + 7°C | COP _d | 5.46 | — |
| T _j = + 12°C | P _{dh} | 33.0 | kW | T _j = + 12°C | COP _d | 7.02 | — |
| T _j = bivalent temperature | P _{dh} | 58.7 | kW | T _j = bivalent temperature | COP _d | 2.49 | — |
| T _j = operation limit temperature | P _{dh} | 65.2 | kW | T _j = operation limit temperature | COP _d | 2.13 | — |
| For air-to-water heat pumps: T _j = - 15°C (if TOL < - 20°C) | P _{dh} | x,x | kW | For air-to-water heat pumps: T _j = - 15°C (if TOL < - 20°C) | COP _d | x,xx | — |
| Bivalent temperature (maximum +2°C) | T _{biv} | -7 | °C | For air-to-water HP: Operation limit tem- perature (maximum -7°C) | TOL | -10 | °C |
| Cycling interval capacity for heating at T _j = -7°C | P _{cyh} | x,x | kW | Heating water operating limit temperature | WTOL | x | °C |
| Degradation coefficient ⁽⁴⁾ at T _j = -7°C | C _{dh} | x,xx | — | Cycling interval efficiency at T _j = +7°C | COP _{cyh} | x,xx | — |
| Cycling interval capacity for heating at T _j = +2°C | P _{cyh} | x,x | kW | Cycling interval efficiency at T _j = +12°C | COP _{cyh} | x,xx | — |
| Degradation coefficient ⁽⁴⁾ at T _j = +2°C | C _{dh} | x,xx | — | Cycling interval efficiency at T _j = +7°C | COP _{cyh} | x,xx | — |
| Cycling interval capacity for heating at T _j = +7°C | P _{cyh} | x,x | kW | Cycling interval efficiency at T _j = +12°C | COP _{cyh} | x,xx | — |
| Degradation coefficient ⁽⁴⁾ at T _j = +7°C | C _{dh} | x,xx | — | | | | |
| Cycling interval capacity for heating at T _j = +12°C | P _{cyh} | x,x | kW | | | | |
| Degradation coefficient ⁽⁴⁾ at T _j = +12°C | C _{dh} | x,xx | — | | | | |
| Power consumption in modes other than active mode | | | | Supplementary heater (to be declared even if not provided in the unit) | | | |
| Off mode | P _{OFF} | 0.04 | kW | Rated heat output (3) | P _{sup} = sup (T _j) | x,x | kW |
| Thermostat-off mode(heating) | P _{TO} | 0.11 | kW | Type of energy input | | | |
| Standby mode | P _{SB} | 0.04 | kW | | | | |
| Crankcase heater mode | P _{CK} | 0.04 | kW | | | | |
| Other items | | | | Outdoor heat exchanger | | | |
| Capacity control | fixed/variable | variable | | For air-to-water HP: Rated air flow rate | Q _{airsource} | 38000 | m ₃ /h |
| Sound power level, indoors | L _{WA} | x | dB(A) | For water-to-water: Rated water flow rate | Q _{watersource} | x | m ₃ /h |
| Sound power level, outdoors | L _{WA} | 89 | dB(A) | For brine-to-water: Rated brine flow rate | Q _{brinesource} | x | m ₃ /h |
| Contact details | Name and address of the manufacturer or its authorised representative. | | | | | | |
| (1) For heat pump space heaters and heat pump combination heaters, the rated heat output Prated is equal to the design load for heating Pdesignh, and the rated heat output of a supplementary heater Psup is equal to the supplementary capacity for heating sup(Tj). (2) If Cdh is not determined by measurement then the default degradation coefficient is Cdh = 0,9. | | | | | | | |

Version:MD17IU-001GW

16127100000437



MAIN OFFICE

Blasco de Garay, 4-6
08960 Sant Just Desvern
(Barcelona)

Tel. +34 93 480 33 22
<http://home.frigicoll.es/>
<http://www.kaysun.es/en/>

MADRID

Senda Galiana, 1
Polígono Industrial Coslada
Coslada (Madrid)

Tel. +34 91 669 97 01
Fax. +34 91 674 21 00
madrid@frigicoll.es